

T-REX TRUCK PRODUCTS INC.

20510

99-04 FORD
MUSTANG
BILLET INSERT

20510

99-04 FORD
MUSTANG
BILLET INSERT

Tools Required:

Phillip Screw Driver
Drill
1/8" Drill Bit
9/32" Socket & Ratchet

Parts List:

1 - Billet Insert
4 - #8 x 3/4 Phillips Screws
4 - #8 Flat Nuts

Read and understand instructions before attempting installation

Step 1

Open the hood and remove the four plastic rivets from along the top of the plastic grille insert and the four 9/32" bolts along the bottom. Remove the plastic grille insert from the bumper cover.

Step 2

Center the insert in the opening. Position the top brackets of the billet grille under the lip of the header panel. Align the billet grille as desired within the opening.

Step 3

Center the insert; Drill and fasten the lower two brackets to the bumper cover using the hardware provided. Drill and fasten the two top brackets to the header panel lip using the hardware provided. The Mustang emblem can be removed from plastic grille and attached to the billet grille using industrial strength 3M brand or similar double-sided tape. Installation complete. ***Thank you for purchasing a T-Rex billet grille.***