

# **T-REX**

**Billet Grilles**

25760

**05-08 NISSAN  
PATHFINDER  
& FRONTIER**

25760

**05-08 NISSAN  
PATHFINDER  
& FRONTIER**

***2005-07 NISSAN PATHFINDER  
2005-08 NISSAN FRONTIER  
With Painted Plastic***

**Recommended Tools:**

Phillips & Slotted Screwdrivers  
5/16 Wrench or Nut-Driver

**Parts List / Hardware:**

1 Bumper Insert (9 Bars)  
2 #8 x 1 Screw (#6 Head)  
2 #8 U-Nuts  
2 1" J Hook Brackets

**Read and understand instructions before attempting installation**

**NOTE: Vehicle must have a PAINTED PLASTIC BUMPER**  
Use part number 25789 for vehicles with a steel chrome bumper.



**Step 1**

Remove the six fasteners holding the top of the grille in place. Pull the grille forward to access the mounting clips on each end; use a slotted screwdriver to unclip the two fasteners on each side. Now remove the grille by depressing the six clips holding the grille to the bumper cover.

**Step 2**

Install a screw into each mounting hole. Slide a u-nut onto each J hook bracket. Center the billet into the bumper opening. Install the screws into the tabs on the billet; secure the J hooks to the screws. Make sure the J hooks wrap around the plastic bars. Use a screwdriver and wrench to tighten the hardware. Do not over-tighten the hardware.



**Step 2**

Re-install the main grille assembly back onto the vehicle.  
***Thank you for purchasing your T-Rex billet grille.*** T-Rex Truck Products Inc. 11/18/05