

25031/25031B
2014 CHEVROLET
CAMARO RS



25031/25031B
2014 CHEVROLET
CAMARO RS

2014 CHEVROLET CAMARO RS

Billet Bumper

TOOLS REQUIRED:

Flat/Phillips Screwdrivers

PARTS LIST

- (1) grille
- (4) 6/32 Toggle Wing
- (4) 6/32X1.5" Machine Screw



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquiries can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Grille Installation

Take the four machine screws and insert them through the front of the billet grille bars and the small square tabs with a hole in the center that are welded to the back of the billet grille, take the four toggle wings and install them onto the machine screws (Fig 1). Place the billet grille with the four screws and toggle wings installed into the bumper cover opening (Fig 2). Using a flat screwdriver reach through the billet bars and spin the toggle wings horizontally so that they insert through the plastic bars in the bumper cover, while holding the toggle with the flat screwdriver use a phillips screwdriver to tighten the machine screws until the billet is secure in the vehicle bumper cover (Fig 3). Installation complete. Thank you for purchasing a T-REX Grille.

