



2013-2018 DODGE RAM 1500 X-Metal Grilles

TOOLS REQUIRED:

Screwdriver
Flat Screwdriver
Diegrinder

PARTS LIST:

(1) Mesh Grille
(10) L-Brackets
(10) 6/32 Nylon Lock Nuts

Install time: 45 Mins.

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.

- Remove Clips to Remove the Plastic Cover. (Fig. 1)
- Remove the Grille Shell.
- Remove the Plastic Grille Support. (Fig. 2)
- Unclip the Plastic Grille Covers with a Flat Screwdriver. (Fig. 3)
- Unclip the Grilles from the Grille Shell and Remove. (Fig. 4)
- With a Diegrinder, Start Cutting the Center and Vertical Bars on the Grille Shell as close to the Outer Grille Shell as possible. (Fig. 5)
- Place the Mesh Grille onto the Grille Shell and Place an L-Bracket and Nylon Lock Nut onto the Threaded Studs. (Fig. 6)

INSTALLATION COMPLETE

