



20516 05-09 FORD MUSTANG GT Models

BILLET INSERT

Recommended Tools:

Phillips Screw Drivers 5/16 Wrench or Nut Driver Drill & 1/8" Drill Bit

Parts List / Hardware:

- Billet Insert (16, 16, 16 Bars)
- 8 6-32 x 2 Machine Screw
- 8 6-32 Nylock Nuts & #6 Flat Washers
- 4 1" J Hooks

Read and understand instructions before attempting installation


Note: Fits GT models with driving lights in the factory grille.

Step 1

Remove the plastic radiator cover from the vehicle; Remove the Mustang logo from the grille. Test fit the billets over the factory grille. The lower mounting tabs have ½" spacers bent at a 90 degree angle. The side billet will only fit one way. Remove the center billet.

Step 2

Mark the mounting tabs on the side billets to the plastic grille. Drill a 1/8" hole at each mark; Use the machine screws, washers and nuts to secure the billets. Do not over-tighten.



Step 3

Insert the machine screws into the tabs on the center insert. From the back of the insert, slide on the J hooks and washers; hand tread the Nylock nuts. Make sure the hooks wrap around the honeycomb mesh. Snug the hardware down until the billet is held firmly in place.

Step 4

Re-install the plastic radiator cover. Use a high quality double-sided tape to secure the factory Mustang logo to the billet insert if desired. *Thank you for purchasing your T-Rex billet grille.* 1/17/05