

**21154**  
**10-12 GMC**  
**TERRAIN**



**21154**  
**10-12 GMC**  
**TERRAIN**

## **10-12 GMC TERRAIN** **Billet Grille 3 Pc.**

### **TOOLS REQUIRED:**

Socket and Ratchet Kit  
Flathead/Phillips Screwdriver

### **PARTS LIST**

(6) 1 1/4" #8 Screws  
(6) 2" Flange Brackets  
(6) U Nut Clips  
(1) Billet Grille Kit 3 Pc.

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION.** Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at [tech@trexbillet.com](mailto:tech@trexbillet.com) to verify fitment or assist with tech questions. All other inquires can be directed to [info@trexbillet.com](mailto:info@trexbillet.com). In the event you do not have internet access please call 1-800-287-5900.

### **Step 1**

Loosen the radiator top cover and side covers. There are several plastic pop clips that you can pry up with a flathead screwdriver and bolts that require removal. This will allow you to get your hand behind the factory grille to install the hardware.

### **Step 2**

Take the billet grilles and insert them into the openings in the factory grille shell.

### **Step 3**

Use the 1 1/4" screws and insert them through the billet bars and through the small square tabs with a hole in them that are welded onto the backside of the billet grilles (Fig 1).

### **Step 4**

From the backside of the grille, install the 2" flange brackets with the u nuts installed on the flange bracket, you will need to pull the top part of the factory grille forward to fit your hand behind the grille (Fig 2). The flange bracket will have the bent ends toward the front of the vehicle. Tighten the screws, replace the radiator covers. Installation complete.

