

**25521**  
**10-12 FORD**  
**MUSTANG GT**



**25521**  
**10-12 FORD**  
**MUSTANG GT**

## **10-12 FORD MUSTANG** **Billet Bumper Grille Short Design GT Models**

### **TOOLS REQUIRED:**

Socket and Ratchet Set  
Flat/Phillips Screwdrivers

### **PARTS LIST:**

(3) 3.5" J-Hooks  
(3) 6/32" Nylon Lock Nuts  
(3) 2" Machine Screws  
(1) Bumper Billet



### **PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE**

**INSTALLATION.** Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at [tech@trexbillet.com](mailto:tech@trexbillet.com) to verify fitment or assist with tech questions. All other inquires can be directed to [info@trexbillet.com](mailto:info@trexbillet.com). In the event you do not have internet access please call 1-800-287-5900.

### **Step 1 Top Radiator Cover Removal**

First you will remove the top radiator cover from the vehicle. There are 8 plastic pop clips on the radiator cover that need to be removed with a flat screwdriver by prying the head upward (Fig 1). Now you can remove the radiator cover. This will give you access to the rear of the factory bumper.

### **Step 2 Bumper Grille Installation**

With the radiator cover removed, place the bumper grille into the factory bumper opening (Fig 2). Now take the two 2" machine screws and insert them through the bilge bars and the small square brackets with holes in the center that are welded to the backside of the billet grille. Reach down through the top where the radiator cover was removed and place the two Custom 4" J-Hooks over the machine screws on the backside of the bumper grille, the bent ends with the holes will face forward and go over the 2" screws, the other end will wrap down and around the black plastic on the lower part of the factory bumper opening. Install the three 6/32" nylon lock nuts and tighten (Fig 3). Reinstall the radiator cover. Installation complete.

