



2013 CADILLAC ATS

Mesh Grille

Install time: 35 Mins.

TOOLS REQUIRED:

**1/16 Drillbit & Drill
Screwdriver**

PARTS LIST:

- (1) Mesh Grille**
- (8) #8 Screws**
- (4) Custom Top Brackets**
- (4) Custom Bottom Brackets**

**PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.**

- **Insert the Custom Top Brackets along the Top of the Mesh Grille. (Fig. 1)**
- **Insert the Custom Bottom Brackets along the Bottom of the Mesh Grille. (Fig. 2)**
- **Place the Mesh Grille onto the Grille Shell. (Fig. 3)**
- **With the Drill, Drill through the Holes that are on the Custom Brackets. (Fig. 4)**
- **Place the #8 Screw where you Drilled the Holes. (Fig. 5)**

INSTALLATION COMPLETE

