

54498

2012 HYUNDAI GENESIS



54498

2012 HYUNDAI GENESIS

2012 HYUNDAI GENESIS

Upper Class Mesh Grille

TOOLS REQUIRED:

Socket and Ratchet Set
Flathead/Phillips Screwdrivers

PARTS LIST

(1) Mesh Grille (1) Top Plate
(9) 6/32 Nylon Lock Nuts
(4) 6/32 Flange Nuts
(9) Flatwashers



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Factory Grille Removal

Open the hood. Remove the twelve plastic pop clips from the black plastic cover plate that is attached to the upper front of the engine compartment by pressing in the center of the pop clip with a pointy object (Fig 1) and pulling the pop clip out of the cover plate. There are also two 10/32" bolts that need to be removed from same plastic cover plate. Remove the plastic cover plate from the vehicle (Fig 2). Now remove two more plastic pop clips (one on each side) from the bumper cover top edge between the factory grille and the headlamps (Fig 3). Remove two phillips screws from the backside of the upper right/left corners of the factory grille, use a small ratcheting phillips screwdriver (Fig 4). There are two more phillips screws located on the back of the factory grille, they are located below the screws you just removed (Note these are a little difficult to reach). Now reach down behind the factory grille and locate the six plastic latches along the bottom and sides of the factory grille. Use your hands or a small flat screwdriver to unlatch them. Pull the factory grille forward and remove it from the vehicle.



Fig 1



Fig 2



Fig 3



Fig 4

Step 2 Upper Class Grille Installation

Now take the Top Plate and install it onto the Mesh Grille, the downward bent tabs will slide over the Threaded Studs on the Mesh Grille (Fig. 5). Install Flatwashers and Nylon Lock Nuts along the four Threaded Studs above the Mesh Grille to secure the Top Plate. On the four Threaded Studs along the bottom of the Mesh Grille, Insert the 6/32 Flange Nuts with the Flatter Wide part facing towards you, Thread many times. (Fig 6). Now take the Mesh Grille and insert it into the Factory Grille Opening, Make sure that the Grille does not go too far in or too far out, once it is in place, Place a Flatwasher onto the Threaded Studs along the bottom of the Mesh Grille and Thread with 6/32 Nylon Lock Nuts (Fig. 7), Tighten Both Nylon and Flange Nuts in Place. Use the plastic pop clips you removed earlier to secure the Top Plate and the radiator cover to the vehicle (Fig. 8). The top plate will be on top of the radiator cover and sit in the indents in the radiator cover.

Installation Complete.

