

54782

08-12 NISSAN
ARMADA



54782

08-12 NISSAN
ARMADA

NISSAN ARMADA **UPPER CLASS SERIES MESH GRILLE**

Tools Required:

Small Slotted Screwdriver
8mm Socket

Part List:

1 Upper Class Grille - Center
2 Upper Class Grille - Sides (Right & Left)
8 6-32 Nylon Lock Nuts
8 1/2" L- brackets

Read and understand instructions before attempting installation

Step 1

Remove the factory grille from the truck. Use a small slotted screwdriver to un-clip the plastic clips. There are two on each end, four along the top and three along the bottom. Now remove the grille.

If you purchased the lower grille install now.



Step 2

Center the grilles into the openings. Use an 8mm wrench to tighten the L brackets using the nylon nuts provided. Make sure the brackets hold to the grille mesh **(1)**. DO NOT OVERTIGHTEN. Be sure to put the plastic clips onto grille shell. Re-install grill assembly back onto the vehicle using lower guides to align grille and clips

Thank you for purchasing a T-Rex Billet Grille.
8/14/07