

52117

55117

2014 CHEVY

SILVERADO 1500



52117

55117

2014 CHEVY

SILVERADO 1500

2014 CHEVY SILVERADO 1500

Upper Class Series Bumper Grille

TOOLS REQUIRED:

Socket and Ratchet Set
Flat Screwdriver
Drill and 1/4" Drill Bit

(2) 1" Black Fender Washers
(2) 10/32" Nylon Lock Nuts
(1) Upper Class Bumper Grille



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1

Test fit the mesh grille in the factory bumper opening. On the backside of the mesh grille are two threaded studs. Note where they make contact with the plastic in the factory bumper opening and mark the point of contact (Fig 1).



Step 2

Now drill a 1/4" hole through the plastic in the factory bumper opening where you made the contact marks (Fig 2). Now insert the mesh grille into the factory bumper opening with the threaded studs on the mesh grille going through the holes that you just drilled.



Step 3

From underneath the vehicle reach up behind the mesh grille and locate the two threaded studs protruding through the plastic. You may need to unclip the rubber splash guard on the bottom of the vehicle to reach the threaded studs. Place the black washers and nylon lock nuts on the threaded studs and tighten the lock nuts. Replace the clips on the splash guard if you removed them.

Installation complete.