

# 55408

11-13 CHRYSLER  
200



# 55408

11-13 CHRYSLER  
200

## 11-13 CHRYSLER 200 Upper Class Bumper Mesh Grille

### TOOLS REQUIRED:

Plastic Prybar  
Ratchet & Socket Set  
Screwdriver

### PARTS LIST:

(1) Bumper Mesh grille  
(4) 6/32 Nylon Lock Nuts  
(4) 10/32 Fender Flatwashers

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS  
BEFORE ATTEMPTING INSTALLATION.

### Step 1

Remove 7 Clips and 2 bolts along the top of the Factory Grille. (Bolts will be re-used.) (Fig. 1)

Lift up the Plastic Cover to remove a Torx Screw that connects the Factory Grille to the Factory Grille Shell. (Fig. 2)

Remove 2 Screws along the bottom of the Factory Grille. (Fig. 3)

Lift the Factory Grille upwards and pull out to remove the Grille. (Fig. 4)

Place the Bumper Mesh Grille over the Factory Bumper Grille. (Fig. 5)

Place a 10/32 Fender Flatwasher and thread with a 6/32 Nylon Lock Nut on the Threaded Screws on the Mesh Grille. (Fig. 6)

Re-Assemble Grille and Clips.

### Installation Complete

