

55895

**05-11 TOYOTA
TACOMA**



55895

**05-11 TOYOTA
TACOMA**

UPPER CLASS SERIES BUMPER

Tools Required:

5/16 Socket

Hardware / Parts List:

- 1 Upper Class Bumper
- 3 6-32 Nylon Lock Nuts
- 3 #6 Flat Washers
- 3 1.5 J Hooks

Read and understand instructions before attempting installation

Step 1

Test fit the bumper grille into the opening. Install a J hook, washer and nut onto each mounting bracket.

Step 2

Wrap the J hooks around the plastic edge in the bumper opening. Tighten the hardware until the grille is held firmly in place. *Thank you for purchasing your T-Rex billet grille.* T-Rex Truck Products Inc.
10/24/06

