

55961

10-12 TOYOTA
TUNDRA



55961

10-12 TOYOTA
TUNDRA

10-12 TOYOTA TUNDRA Upper Class Bumper Grille 3 Pc.

TOOLS REQUIRED

Socket and Ratchet Set

PARTS LIST

- (6) 1/2" L-Brackets
- (6) 6/32" Nylon Lock Nuts
- (1) Upper Class Mesh Grille 3 Pc.

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquiries can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Install

Open the vehicles hood. Take the 3 bumper grilles and install them into the appropriate openings (Fig 1). From behind the bumper grille, reach down behind the bumper and locate the threaded studs. Install a 1/2" L-Bracket on each of the threaded studs making sure the L-Brackets latch over the horizontal plastic ribs (Fig 2). Install the 6/32" nylon lock nuts on the threaded studs and tighten. Installation complete.

