



2011-13 Polaris XP SERIES

Side Vents

Install time: 15 Mins.

TOOLS REQUIRED:

Screwdriver

PARTS LIST:

- (2) Side Vents
- (2) 6/32 1" Button Head Screws
- (2) Custom L-Brackets
- (2) Springs



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

- Insert the Button Head Screw through the hole on the Grille and place the Spring and L-Bracket Through the Screw (L-Bracket will face towards the back of the Side Vent shown in Fig. 2)
- Remove the Factory Side Vent (just Pop off carefully).
- Insert the Side Vent into the Factory Opening. (Fig. 1)
- Make sure that the L-Bracket is Vertical. (Fig. 2)
- Start Threading in the Screw. (Fig. 3)

INSTALLATION COMPLETE

