



Platinum Series Bug Shield
No Drill BUG DEFLECTOR

Installation Instruction: 34786 / 34782

- 1) Thoroughly clean front hood area.
- 2) Open Hood.
- 3) Loosen the bolts which hold the grill to the hood (on some vehicles they may need to be removed).
- 4) Pull the grill forward and slide the bugshield between the grill and the hood.
- 5) Position the bugshield in the center of the hood and reinstall, or re-tighten the bolts. **DO NOT OVER TIGHTEN BOLTS.**
- 6) Do not attach the clear rubber bump-ons to the shield or the warranty will be voided. It is essential for the clear rubber bump-ons to be attached to the vehicle hood or damage will occur. Use the alcohol prep pads to clean the area, where the shield touches the vehicle, large enough to affix the rubber bump-ons. Gently hold the shield away from the hood and place the bump-ons on the vehicle, between the shield and hood. Make certain that the bump-ons are positioned to keep the shield from contacting hood
- 7) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.



Platinum Series Bug Shield
No Drill BUG DEFLECTOR

Installation Instruction: 34786 / 34782

- 1) Thoroughly clean front hood area.
- 2) Open Hood.
- 3) Loosen the bolts which hold the grill to the hood (on some vehicles they may need to be removed).
- 4) Pull the grill forward and slide the bugshield between the grill and the hood.
- 5) Position the bugshield in the center of the hood and reinstall, or re-tighten the bolts. **DO NOT OVER TIGHTEN BOLTS.**
- 6) Do not attach the clear rubber bump-ons to the shield or the warranty will be voided. It is essential for the clear rubber bump-ons to be attached to the vehicle hood or damage will occur. Use the alcohol prep pads to clean the area, where the shield touches the vehicle, large enough to affix the rubber bump-ons. Gently hold the shield away from the hood and place the bump-ons on the vehicle, between the shield and hood. Make certain that the bump-ons are positioned to keep the shield from contacting hood
- 7) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.