



INSTRUCTIONS—INSTRUCCIONES—CONSIGNES

APPLICATION: FORD SUPER DUTY (F250/350/450/550) 2008-2010
PART NUMBER: 37-02360, 37-02365

ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	1	LIGHT BAR ASSEMBLY	

1. Remove contents from box. Verify that all parts listed are present and free from damage. Read installation instructions carefully before attempting installation.
2. Remove the (X4) 18MM front tow hook bolts and nut plates from the front bumper. It is recommended to support the front bumper with a jack stand to keep proper alignment.
3. Install the light bar assembly to the front of the vehicle using the factory tow hook bolts and nut plates. Align front bumper and light bar as desired and tighten fasteners. Tighten to 30-45 lbs/ft.



Westin Automotive Products, Inc.
5200 N. Irwindale Ave. Ste 220
Irwindale, Ca 91706

Thank You for choosing Westin products
For additional installation assistance please call
Customer Service (800)793-7846