

INSTALLATION INSTRUCTIONS

EXP TRUCK CAP




APPLICATION:
2009-2025 Ram 1500 Classic 6' 4" Bed


PART NUMBER: 16-14735S
16-14735

CONTENT			
ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	1	ROOF PANEL	13mm SOCKET
2	1	FRONT PANEL (SLIDING WINDOW OPTIONAL)	12mm SOCKET
3	1	LEFT SIDE PANEL	10mm SOCKET
4	1	RIGHT SIDE PANEL	RATCHET
5	1	REAR DOOR	TORQUE WRENCH
6	1	PARTS KIT #1	5MM ALLEN KEY
7	1	PARTS KIT #2	PHILLIPS SCREW-DRIVER
8	1	PARTS KIT #3	1/4" DRILL BIT
9	1	RUBBER BED STRIP	DRILL
10	1	INTERIOR LIGHT HARNESS	SILICONE SEALANT
11	1	LOCK/UNLOCK HARNESS	ELECTRICAL TAPE

ANTI-SEIZE LUBRICANT MUST BE USED ON ALL STAINLESS STEEL FASTENERS TO PREVENT THREAD DAMAGE AND GALLING




ITEM 1



ITEM 2


S-MODEL SLIDING WINDOW




ITEM 3



ITEM 4




ITEM 5



ITEM 6

front corner cover

rear corner cover



PROCEDURE

1. Remove contents from box, verify if all parts listed are present and free from damage.
Carefully read and understand all instructions before attempting installation.
Failure to identify damage before installation could lead to a rejection of any claim.
2. With the roof panel secured on a flat surface, slide the rear door into the roof panel. (**Fig. 1**)
3. Next, use a Phillips screwdriver to screw the three (3) #6 x 3/8 pan head tapping screws from **Parts Kit #1 (Item 6)** to secure the rear door panel onto the roof panel. Cross section view A-A shows how the railing system works to attach these components together. (**Fig. 2**)

FIGURE 1






FIGURE 2



A-A




WESTIN


Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773

Thank you for choosing Westin products
for additional installation assistance please call
Customer Service (800) 793-7846
www.westinautomotive.com

4. Screw in the rear door side covers using the two (2) #7 x 1/2 flat head tapping screws from **Parts Kit #1 (Item 6)**. The installation should look like the image below. (**Fig. 3**)




5. While lifting the rear door up, slide the left panel into the railing system. Section view A-A shows how the left panel slides into the roof panel. (**Fig. 4**)




6. Repeat step 5 for the right panel. (**Fig. 5**)

FIGURE 5



7. Next, push the front panel into the roof panel. (**Fig. 6**)

FIGURE 6




WESTIN




Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773

8. Push the left panel inwards towards the front panel. Using a front panel bracket, two (2) M8 x 12 socket pan head bolts, two (2) M8 split washers, two (2) M8 flat washers, two (2) M6 x 15 hex bolts, two (2) M6 split washers, and two (2) M6 flat washers provided in **Parts Kit #1 (Item 6)**, fasten the left panel to the front panel. Use a 5mm Allen Key and 10mm socket to initially tighten the bolts, then use a torque wrench to torque the M8 bolts to **10Nm (8ft-lbs)** and the M6 bolts to **5Nm (4 ft-lbs)**. Repeat this process to fasten the right panel to the front panel. (Fig. 7)



CAUTION: MAKE SURE TO USE THE M8 X 12 SOCKET PAN HEAD BOLTS FOR THE MOUNTING HOLES ON THE FRONT GLASS, THEY REQUIRE A 5MM ALLEN KEY TO FASTEN. DO NOT USE THE M8 X 20 HEX BOLTS AS THIS MAY DAMAGE THE FRONT GLASS PANEL.





9. Connect the front wire found at the corner of the roof panel and front panel (Fig. 8). Then connect the rear wire (Fig. 9) and tuck the connectors into the roof panel. (Fig. 10)



10. Next, use two (2) M8 x 20 hex bolts, two (2) M8 split washers, and two (2) M8 flat washers to fasten the front panel to the roof panel at one corner. Use a 12mm socket to initially tighten the bolts, then torque the bolts to **10Nm (8ft-lbs)**. Repeat this process for the other corner where the roof panel and front panel meet. (**Fig. 11**)




11. Repeat Step 10 for both corners where the roof panel and rear door meet. Use the same kind of hardware as in the previous step (**Fig. 12**). Connect the roof panel wire to the rear door connector as shown below. (**Fig. 13**)



Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773

12. Slide the water channels downwards on the left and rear panels toward the rear door (**Fig. 14**). The water channels are found in **Parts Kit #3 (Item 8)**.

FIGURE 14



13. An inside corner of the rear door and side panel is shown below. Using the contents of **Parts Kit #3 (Item 8)** and a 12mm socket, fasten two (2) M8 x 20 hex bolts through the water channel bracket and into the side panel, torque to **10Nm (8ft-lbs)**. (**Fig. 15**) Next, use two (2) #6 x 3/8 pan head tapping screws and fasten the water channels to the side panels. (**Fig. 16**) Repeat this step for the other side of the topper.

FIGURE 15






FIGURE 16



14. Torque the nuts on the door latch to **5Nm (4ft-lbs)** using a 10mm socket. There are slots on the door latch bracket that allow for the latch to be adjusted so the rear door can close correctly. (**Fig 17**) Once the rear door is shut and the door latch is adjusted properly, torque the bolts in **Fig. 18** to **10Nm (8ft-lbs)**.

SLOTS FOR ADJUSTABILITY

FIGURE 17






FIGURE 18



WESTIN

Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773

15. Next, clean the surface of the perimeter of the corner where the roof panel and left panel meet. Locate the silicone corner covers in **Parts Kit #1 (Item 6)** and remove the tape over the adhesive on the covers. While tucking the wires inwards into the roof panel, firmly press the cover over the corner (**Fig. 19**). Fasten the corner cover to the topper assembly using one (1) M6 x 10 pan head bolt and one (1) M6 flat washer also found in the same parts kit. The hardware fastens from the inside of the topper assembly. Repeat this step for installing the corner cover on the other side where the right panel meets the roof panel. (**Fig. 20**)

FIGURE 19





FIGURE 20





Pan Head Bolt M6x10



16. Repeat the process in Step 14 to install the corner covers on the rear corners of the topper assembly. (**Fig. 21**)

FIGURE 21



WESTIN

Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773

17. Remove the adhesive on the included rubber strip (**Item 9**) and install it onto the front edge of the bed. (**Fig. 22**) Open the left, right, and rear panels before placing the topper onto the truck bed. A minimum of four people are recommended for the topper installation. Make sure to avoid dragging the topper across the truck bed rails. Handle with caution to avoid injury to hands and damage to the topper assembly and vehicle. (**Fig. 23**)

FIGURE 22





FIGURE 23



18. Locate the contents found in **Parts Kit #2 (Item 7)** and correctly place each labeled clamp on both bed rails (**Fig. 24**). Use a 13mm socket to initially tighten the clamps, then torque to **6Nm (4.4ft-lbs)**. The tightened clamp should resemble (**Fig. 25**).

FIGURE 24






FIGURE 25



WESTIN


Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773

19. Once the bed topper is placed on the vehicle, adjustment may be required to allow for the topper to sit well onto the bed rails. If adjustment is needed, loosen the front bracket and push the sides doors inward towards each other and make sure the gap (**circled in Fig. 26**) is closed. Tighten the front bracket as mentioned in Step 8.
20. Use the nuts already installed on the end of the gas studs to secure the studs to the rear door using a 12mm socket. (**Fig. 27**)

FIGURE 26





FIGURE 27



21. Plug the Lock/Unlock Harness (**Item 11**) into the wire coming from the driver side front corner of the topper (**Fig. 28**). Tuck the connector into the topper using the provided rubber grommet.

FIGURE 28



Topper Lock/Unlock Wiring Instructions (Classic Trims without Autolock Tailgate)

22. To enable the topper's lock/unlock feature, remove the driver side door sill panel (Fig. 29). Lift the driver side floorboard carpet, and the black carpet under it, and locate the black plastic cover (Fig. 30-31).
23. Drill a small 1/4" hole through the cover from above the floorboard.



FIGURE 29



FIGURE 30



FIGURE 31


Truck Cap Lock/Unlock Wiring Instructions (Classic Trims without Autolock Tailgate)

24. Next, route the truck cap's wiring harness from the front left of the truck cap, to underneath the vehicle, towards the driver side floor board. Remove the splice connectors and feed the harness from under the vehicle, through the hole drilled in the plastic cover, and into the driver floor area (**Fig. 32**). Make sure the harness is safely secured to the vehicle's frame and does not make contact with any exhaust or moving components.
25. Use silicon sealant to seal the hole which makes the floorboard waterproof.
26. Open the black plastic housing to reveal a strand of wires (**Fig. 33**).
27. Use the provided splice connectors to splice the red truck cap wire to the green wire with a dark blue stripe. Next, splice the black truck cap wire to the violet wire with a green stripe.
28. Test that the truck cap locks and unlocks with the vehicle's key fob and doors. Reverse the wiring order of Step 26 if the locking/unlocking of the truck cap is inversed relative to the vehicle's doors.
29. Use electrical tape or similar harness tape to wrap the large strand vehicle wiring harness and the truck cap's wires.
30. Place the strand back into the black plastic housing, clip the carpet back onto the housing, and reinstall the driver side door sill panel.

FIGURE 32



RE-WRAP AFTER SPLICING IS COMPLETE



Truck Cap Lock/Unlock Wiring Instructions (Classic Trims with Autolock Tailgate)

31. The following steps are for Ram 1500 Classic trims that have a tailgate with an lock/unlock feature from the key fob.
32. Open the tailgate and remove the tailgate cover by loosening the 10 screws (**Fig. 34**).
33. Route the truck cap's wiring harness from the front left of the truck cap, to underneath the vehicle, towards the lower area of the tailgate. The wires can then be fed into the lower region of the tailgate to the handle.
34. Locate the wiring connector on the lock actuator within the tailgate (**Fig. 35**).
35. Use the provided splice connectors to splice the red truck cap wire to the green/dark blue wire. Then splice the black truck cap wire to the violet/green wire (**Fig. 36-37**).




FIGURE 34




FIGURE 35

Splice red topper
wire to green/dark

Splice black topper
wire to violet/green




FIGURE 36




FIGURE 37

WESTIN

Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773

Brake Light Wiring Instructions

36. Remove the tail light by removing the fasteners and clips, locate the tail light connector (**Fig 38**).
37. Then, splice the yellow wire from the topper's harness into the white/green wire of the tail light. Splice the red topper wire into one of the black wires. (**Fig. 39**) Finally, test and make sure the brake light works correctly.
38. Reinstall the brake light.

Note: Brake light will flash with right turn signal.




FIGURE 38




FIGURE 39

LED INTERIOR LIGHT

39. Plug the provided Interior Light Harness (**Item 10**) at the connector coming from the rear driver side of the topper (**Fig 40**). Tuck the harness into the topper using the rubber grommet (**Fig 41**). The other end of the harness will need to go to the vehicle's battery. Route the harness underneath the vehicle, make sure to avoid any moving parts or exhaust components.

A key set is included in the topper packaging.

The installation of your Westin Automotive Truck Cap is complete!




FIGURE 40




FIGURE 41



FIGURE 42

WESTIN

Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773



WARNING



Failure to follow these instructions could lead to death, personal injury, and / or property damage.

Failure to follow these instructions could lead to death, personal injury, and / or property damage.

FASTENERS:

All Westin supplied fasteners must be utilized and installed in accordance with the installation instructions and apply torque to the specifications as defined. **DOUBLE CHECK ALL FASTENERS BEFORE INITIAL USE, AND PERIODICALLY IN THE FUTURE TO ENSURE PROPER FUNCTION AND SAFETY.**

DRILLING:

Most Westin products do not require drilling for installation. If drilling is defined as required, use caution when drilling a vehicle. **FAILURE TO REVIEW AN AREA TO BE DRILLED MAY RESULT IN PERSONAL INJURY AND/OR INJURY TO OTHERS AS WELL AS VEHICLE DAMAGE.**

EYE PROTECTION:

ALWAYS WEAR SAFETY GLASSES OR GOGGLES DURING THE INSTALLATION PROCESS TO AVOID PERSONAL INJURY.

MAXIMUM TOWING/CARRYING CAPACITY: (if applicable)

The Westin Receiver Hitches will have a visible tow rating label affixed directly on the product. User should never exceed the vehicle manufacturers maximum tow and weight rating regardless of the capacity of the hitch. **FAILURE TO FOLLOW THESE GUIDELINES WILL VOID THE WESTIN WARRANTY AND MAY RESULT IN PERSONAL INJURY AND/OR INJURY TO OTHERS AS WELL AS VEHICLE DAMAGE.**

FOR CALIFORNIA RESIDENTS ONLY-PROP 65 WARNING:

Some products may contain chemicals such as DEHP, which can cause cancer, birth defects or other reproductive harm. For more info go to www.p65warnings.ca.gov



Westin Automotive Products, Inc.
320 W. Covina Blvd
San Dimas, Ca. 91773