



SIGNATURE OF QUALITY

AUTOMOTIVE PRODUCTS, INC.



INSTALLATION INSTRUCTIONS

APPLICATION: ULTIMATE BULL BAR2015 & UP CHEVY TAHOE AND SUBURBAN
APP PART # 32-3620 & 32-3625

ITEM	QUANTITY	DESCRIPTION	TOOLS NEEDED
1	1	BULL BAR ASSEMBLY	RATCHET
2 / 3	2	MOUNTING BRACKETS— DRIVER / PASSENGER	UTILITY KNIFE
4	6	M12 HEX HEAD CAP SCREW (YELLOW ZINC)	18MM SOCKET
5	12	M12 FLAT WASHER (YELLOW ZINC)	ALLEN WRENCH
6	6	M12 LOCK WASHER (YELLOW ZINC)	9/16" WRENCH
7	6	M12 HEX NUT (YELLOW ZINC)	TORQUE WRENCH
8	4	3/8" BUTTON HEAD BOLT (STAINLESS)	18MM WRENCH
9	8	3/8" FLAT WASHER (STAINLESS)	
10	4	3/8" LOCK WASHER (STAINLESS)	
11	4	3/8" HEX NUT (STAINLESS)	

ANTI-SEIZE LUBRICANT MUST BE USED ON ALL STAINLESS STEEL FASTENERS TO PREVENT THREAD DAMAGE AND GALLING



1. Remove contents from box, verify if all parts listed are present and free from damage. Carefully read and understand all instructions before attempting installation.
2. Remove factory tow hooks (if equipped). They cannot be re-used.
3. Trim the plastic in the area shown in Figure 1. Repeat for the passenger side.
4. Loosely install the Driver Side Mounting Bracket using the supplied M12 hardware as shown in Figure 2. Repeat for the passenger side.



Westin Automotive Products, Inc.
320 Covina Blvd
San Dimas, Ca. 91773

Thank You for choosing Westin products
For Additional installation assistance please call
Customer service (800) 793-7846
www.westinautomotive.com

5. Remove the factory front license plate holder. It cannot be re-used.
6. With assistance hold the Bull Bar up to the previously installed brackets. Loosely attach the Bull Bar to the brackets using the supplied 3/8" hardware. Refer to Figure 3.
7. Align and adjust the Bull Bar as necessary. Tighten and torque all hardware: 3/8" to 20-25 ft-lbs., M12 to 50-55 ft-lbs.
8. Westin offers a Bull Bar Front License Relocator Kit (P/N 32-0055) for use on vehicles registered in states that require a front license plate.



CARE INSTRUCTIONS:

- REGULAR WAXING IS RECOMMENDED. DO NOT USE ANY TYPE OF POLISH OR WAX THAT MAY CONTAIN ABRASIVES.
- STAINLESS STEEL PRODUCTS CAN BE CLEANED WITH MILD SOAP AND WATER. STAINLESS STEEL POLISH SHOULD BE USED TO POLISH SMALL SCRATCHES.
- GLOSS BLACK FINISHES SHOULD BE CLEANED WITH MILD SOAP AND WATER.



Westin Automotive Products, Inc.
320 Covina Blvd
San Dimas, Ca. 91773

Thank You for choosing Westin products
For Additional installation assistance please call
Customer service (800) 793-7846
www.westinautomotive.com