



Platinum Series Bug Shield

No Drill BUG DEFLECTOR
Installation Instruction: FF

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood (this will help verify if you have the correct shield for your vehicle).
- 3) Remove the two rubber bumpers near the center of the hood.
(Not all vehicles have the rubber bumpers mentioned)
Before locking push pin in place make certain the shield is properly centered by "eyeballing" the two ends (you may need to move the shield to either the left or right).
- 4) Push in Locking Pin. Install Tip: It is possible to push the pin in with only the use of your hand. But, if you are unable to do this, due to the tight fit of the locking pin, we would suggest LIGHTLY tapping it in with the use of a hammer.
- 5) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

5- 14010 Push Pin

www.wadeauto.com
www.westinautomotive.com



Platinum Series Bug Shield

No Drill BUG DEFLECTOR
Installation Instruction: FF

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bugshield by holding it up to the hood (this will help verify if you have the correct shield for your vehicle).
- 3) Remove the two rubber bumpers near the center of the hood.
(Not all vehicles have the rubber bumpers mentioned)
Before locking push pin in place make certain the shield is properly centered by "eyeballing" the two ends (you may need to move the shield to either the left or right).
- 4) Push in Locking Pin. Install Tip: It is possible to push the pin in with only the use of your hand. But, if you are unable to do this, due to the tight fit of the locking pin, we would suggest LIGHTLY tapping it in with the use of a hammer.
- 5) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

5- 14010 Push Pin

www.wadeauto.com
www.westinautomotive.com