



Jeep Top Wind Deflector

WindGuard

Installation Instructions

PLEASE READ THESE INSTRUCTIONS BEFORE INSTALLATION

This installs easier with the help of a friend

It is important to read the instructions fully before fitting. The double-sided tape adheres and cures best at temperatures above 65 degrees (F). If the Windguard is being fitted below 65 degrees, it is advisable to warm the contact area of the vehicle (a hot air gun or hair dryer may be used.)

- 1) Trial fit the Windguard without removing the masking from the double-sided tape, along the painted top edge about the windshield . Take note of the contact area.
- 2) With the alcohol pad provided, thoroughly clean the area where the tape will adhere. After cleaning, wipe dry with a clean, dry cloth. (NOTE: the area where the tape adheres must be clean and dry, and should not be touched after cleaning.)
- 3) Remove the masking from the double-sided tape.
- 4) Carefully position the Jeep Top Windguard in the center of the vehicle, about ¼ of an inch above the windshield seal, lightly touch the tape against the contact area. If the position of the Windguard is correct, rub over the taped edge firmly with a soft cloth to fully adhere the tape.
- 5) **REQUIRES 48 HOURS TO CURE.** Do not wash vehicle for 48 hours after installation.

CLEANING INSTRUCTIONS: WASH WITH LOTS OF WARM WATER AND A MILD SOAP SOLUTION USING A SOFT, CLEAN CLOTH OR SPONGE. USE OF CLEANERS NOT APPROVED FOR ACRYLIC, OR USE OF IMPROPER SOLVENTS COULD RESULT IN PERMANENT DAMAGE WHICH WILL NOT BE COVERED BY WARRANTY.

WINDGUARDS ARE MADE OF BREAKAGE RESISTANT MATERIAL, BUT TO AVOID DAMAGE, MACHINE CAR WASHES ARE NOT ADVISED.



Jeep Top Wind Deflector

WindGuard

Installation Instructions

PLEASE READ THESE INSTRUCTIONS BEFORE INSTALLATION

This installs easier with the help of a friend

It is important to read the instructions fully before fitting. The double-sided tape adheres and cures best at temperatures above 65 degrees (F). If the Windguard is being fitted below 65 degrees, it is advisable to warm the contact area of the vehicle (a hot air gun or hair dryer may be used.)

- 1) Trial fit the Windguard without removing the masking from the double-sided tape, along the painted top edge about the windshield . Take note of the contact area.
- 2) With the alcohol pad provided, thoroughly clean the area where the tape will adhere. After cleaning, wipe dry with a clean, dry cloth. (NOTE: the area where the tape adheres must be clean and dry, and should not be touched after cleaning.)
- 3) Remove the masking from the double-sided tape.
- 4) Carefully position the Jeep Top Windguard in the center of the vehicle, about ¼ of an inch above the windshield seal, lightly touch the tape against the contact area. If the position of the Windguard is correct, rub over the taped edge firmly with a soft cloth to fully adhere the tape.
- 5) **REQUIRES 48 HOURS TO CURE.** Do not wash vehicle for 48 hours after installation.

CLEANING INSTRUCTIONS: WASH WITH LOTS OF WARM WATER AND A MILD SOAP SOLUTION USING A SOFT, CLEAN CLOTH OR SPONGE. USE OF CLEANERS NOT APPROVED FOR ACRYLIC, OR USE OF IMPROPER SOLVENTS COULD RESULT IN PERMANENT DAMAGE WHICH WILL NOT BE COVERED BY WARRANTY.

WINDGUARDS ARE MADE OF BREAKAGE RESISTANT MATERIAL, BUT TO AVOID DAMAGE, MACHINE CAR WASHES ARE NOT ADVISED.