



Platinum Series Bug Shield  
No Drill BUG DEFLECTOR  
Installation Instruction: P

BEFORE YOU BEGIN INSTALLING THIS SHIELD, PLEASE NOTE THAT THE SHIELD INCLUDES BOTH TAPE AND SCREWS. DETERMINE WHERE THE TAPE WILL ADHERE TO THE VEHICLE AND THOROUGHLY CLEAN THE CONTACT AREA WITH MILD SOAP AND WATER. THEN MAKE SURE IT IS CLEAN USING THE ALCOHOL PADS PROVIDED.

- 1) Thoroughly clean front hood area.
- 2) Open Hood.
- 3) Loosen the bolts which hold the grill to the hood
- 4) Pull the grill forward and slide the bugshield between the grill and the hood.
- 5) Position the bugshield in the center of the hood and reinstall, or re-tighten the bolts. **DO NOT OVER TIGHTEN BOLTS.**
- 6) Slide outer tags OUT until they match the hoods contour. Remove tape masking and hold in position until tape adheres to hood.
- 7) We have also provided you with two screws and grommets. These are provided as a secondary installation. The 3M tape has been developed and formulated specifically for the automotive market. If you feel the tape will not be enough carefully drill a hole in the appropriate place with a 1/8" drill bit. **IMPORTANT:** Take care not to drill through or damage the top of the hood. Then install the screws with the grommets. **DO NOT OVER TIGHTEN SHIELD.**
- 8) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

2-#10 X 1/2 Phillip Truss, 2- Grommet - Tape on two outside tags  
[www.wadeauto.com](http://www.wadeauto.com)  
[www.westinautomotive.com](http://www.westinautomotive.com)



Platinum Series Bug Shield  
No Drill BUG DEFLECTOR  
Installation Instruction: P

BEFORE YOU BEGIN INSTALLING THIS SHIELD, PLEASE NOTE THAT THE SHIELD INCLUDES BOTH TAPE AND SCREWS. DETERMINE WHERE THE TAPE WILL ADHERE TO THE VEHICLE AND THOROUGHLY CLEAN THE CONTACT AREA WITH MILD SOAP AND WATER. THEN MAKE SURE IT IS CLEAN USING THE ALCOHOL PADS PROVIDED.

- 1) Thoroughly clean front hood area.
- 2) Open Hood.
- 3) Loosen the bolts which hold the grill to the hood
- 4) Pull the grill forward and slide the bugshield between the grill and the hood.
- 5) Position the bugshield in the center of the hood and reinstall, or re-tighten the bolts. **DO NOT OVER TIGHTEN BOLTS.**
- 6) Slide outer tags OUT until they match the hoods contour. Remove tape masking and hold in position until tape adheres to hood.
- 7) We have also provided you with two screws and grommets. These are provided as a secondary installation. The 3M tape has been developed and formulated specifically for the automotive market. If you feel the tape will not be enough carefully drill a hole in the appropriate place with a 1/8" drill bit. **IMPORTANT:** Take care not to drill through or damage the top of the hood. Then install the screws with the grommets. **DO NOT OVER TIGHTEN SHIELD.**
- 8) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

2-#10 X 1/2 Phillip Truss, 2- Grommet - Tape on two outside tags  
[www.wadeauto.com](http://www.wadeauto.com)  
[www.westinautomotive.com](http://www.westinautomotive.com)