



## Platinum Series Bug Shield

### No Drill BUG DEFLECTOR Installation Instruction: YY

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bug shield by holding it up to the hood. Note which holes in your vehicle line up with the holes in your bug shield. (This will also help verify if you have the correct shield for your vehicle.)
- 3) Place the large washers onto the well-nut and insert the rubber well-nuts into the square holes (that correspond with the holes on your shield.)
- 4) Place washer on well-nut screw and install shield onto hood.  
(Install tip: The well-nut is a compression unit. It may not feel like you are screwing in anything at all for a moment. The secret is to keep enough pressure on the shield so the well-nut does not fall out.)

#### **DO NOT OVER TIGHTEN SCREW OR YOU WILL VOID THE WARRANTY.**

- 5) Before closing the hood make certain the shield is properly centered by "eyeballing" the two ends (you may need to loosen the screws and move the shield to either the left or right.)
- 6) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

4- 8/32 Well Nut, 4- 8/32 x 5/8 Screw, 4- #10 Black Washer, 4- BAS Washer

[www.wadeauto.com](http://www.wadeauto.com)  
[www.westinautomotive.com](http://www.westinautomotive.com)



## Platinum Series Bug Shield

### No Drill BUG DEFLECTOR Installation Instruction: YY

- 1) Thoroughly clean front hood area. Open hood.
- 2) "Dry Fit" the bug shield by holding it up to the hood. Note which holes in your vehicle line up with the holes in your bug shield. (This will also help verify if you have the correct shield for your vehicle.)
- 3) Place the large washers onto the well-nut and insert the rubber well-nuts into the square holes (that correspond with the holes on your shield.)
- 4) Place washer on well-nut screw and install shield onto hood.  
(Install tip: The well-nut is a compression unit. It may not feel like you are screwing in anything at all for a moment. The secret is to keep enough pressure on the shield so the well-nut does not fall out.)

#### **DO NOT OVER TIGHTEN SCREW OR YOU WILL VOID THE WARRANTY.**

- 5) Before closing the hood make certain the shield is properly centered by "eyeballing" the two ends (you may need to loosen the screws and move the shield to either the left or right.)
- 6) Close hood and tell all your friends about your FANTASTIC new shield from WADE.

Cleaning Instructions: Wash with warm water and a mild soap solution using a soft, clean cloth or sponge. Use of cleaners not approved for acrylic, or use of improper solvents could result in permanent damage which will not be covered by the warranty.

Warning: All items are made of breakage resistant material, but to avoid damage, machine car washes are not advised.

4- 8/32 Well Nut, 4- 8/32 x 5/8 Screw, 4- #10 Black Washer, 4-BAS Washer

[www.wadeauto.com](http://www.wadeauto.com)  
[www.westinautomotive.com](http://www.westinautomotive.com)