# 1994-2000 CHEV 6.5L DOWN PIPE

## For 4-Bolt Convertor Mounting

#### EXHAUST KIT # 1046550 INSTALLATION INSTRUCTIONS

Check to ensure all parts contained in the kit are received and in good order

COMPONENT	PART #	QTY
PLUG 1/4NPT	1040147	1
PIPE, TURBO OUT 1994 - UP 6.5L	1406550	1
CAP SCREW	1406551	4
LOCK WASHER	1406552	4
NUT	1406553	4
GASKET, 6.5L 4 - BOLT FLANGE - CAT	15954812	1

#### READ ALL INSTRUCTIONS CAREFULLY BEFORE INSTALLATION



- Raise vehicle on a hoist or safety stands to provide access to the exhaust system.
- 2) Loosen the bolts at the flange of the catalytic convertor and pry the hanger pin from the hanger.

#### HINT: Unhook some or all exhaust hangers to help with removal.

3) Remove the clamp securing the turbo down pipe to the turbo outlet and remove pipe. Separate the pipe assembly.

\*\*CAUTION\*\* BE SURE TO SUPPORT THE CATALYTIC CONVERTOR IF NOT REMOVING IT. CONVERTOR IS HEAVY AND DAMAGE AND/OR INJURY MAY RESULT.

#### NOTE: If not installing a pyrometer, secure plug in turbo outlet pipe.

- 4) Position the new down pipe on the outlet of the turbo and install clamp loosely to hold pipe in place (you will need to twist pipe slightly while installing other components). If more clearance is required, bend back the lip of the firewall and floorboard.
- 5) Position the flange gasket over the end of the down pipe and install the convertor inlet pipe. Connect all support hangers and position pipes for proper clearance from underbody components.
- 6) Tighten exhaust clamps at turbo outlet and pipe joints.
- 7) Start engine to check for leaks and exhaust components touching frame or underbody structures. Loosen clamps and adjust as required to seal leaks and maintain clearance, then secure clamps.

For technical assistance call, fax, or E-mail the BD Technical Department, Monday to Friday, 8:30am to 4:30pm Pacific Time.

### <u>BD ENGINE BRAKE</u> DISCLAIMER OF LIABILITY

Other than as expressly set forth herein, BD ENGINE BRAKE, Inc. (hereafter collectively, "SELLER"), together with its distributors, jobbers and dealers shall in no way be responsible for the PRODUCT'S proper use and service. In no event shall SELLER be liable for any special, incidental, indirect or consequential damages of any kind or nature, whether or not BUYER was advised of the possibility of damage, arising or resulting from the use or performance of the PRODUCT, and BUYER hereby waives any and all such claims.

BUYER acknowledges that he/she/it is not relying on SELLER'S skill or judgment to select or furnish goods suitable for any particular purpose and that SELLER has no liability that will extend beyond the scope of the limited warranty contained herein, and BUYER hereby waives all remedies or liabilities, expressed or implied, arising by operation of law or otherwise, (including, without limitation, any obligations of SELLER with respect to fitness for any particular purpose; merchantability; and special, incidental, indirect or consequential damages) or whether or not occasioned by SELLER'S negligence.

SELLER disclaims any warranty and expressly disclaims any liability for personal injury or damages related to BUYER'S use of the PRODUCT. BUYER acknowledges and agrees that the disclaimer of any liability for personal injury is a material term for this agreement and BUYER agrees to indemnify SELLER and hold SELLER harmless from any claim related to the PRODUCT and its use or performance. Under no circumstances will SELLER be liable for any damages, liabilities, costs or expenses incurred as a result of by reason of the use, performance or sale of the PRODUCT, including, without limitation, any damages, liabilities, costs or expenses incurred by reason of BUYER'S negligence related to those uses of the PRODUCT as a result of the removal of the performance product.

SELLER assumes no liability regarding the improper installation or misapplication of the PRODUCT. It is the installer's responsibility to check for proper installation, and, if in doubt, contact the manufacturer.

#### LIMITATION OF WARRANTY

SELLER hereby provides the following limited warranty as to description, quality, merchantability, fitness for any product's purpose, productiveness, or any other matter of SELLER'S product sold herewith. The SELLER shall be in no way responsible for the product's open use and service and the BUYER hereby waives all rights other than those expressly written herein. This Warranty shall not be extended or varied except by a written instrument signed by SELLER and BUYER.

The Warranty is Limited to one (1) year from the date of sale and limited solely to the parts contained within the product's kit. All products that are in question of Warranty must be returned shipping prepaid to the SELLER and must be accompanied by a dated proof of purchase receipt. All Warranty claims are subject to approval by BD ENGINE BRAKE, Inc.

Under no circumstances shall the SELLER be liable for any labor charged or travel time incurred in diagnosis for defects, removal, or reinstallation of this product, or any other contingent expenses.

Under no circumstances will the SELLER be liable for any damage or expenses insured by reason of the use or sale of any such equipment.

IN THE EVENT THAT THE BUYER DOES NOT AGREE WITH THIS AGREEMENT: THE BUYER MAY PROMPTLY RETURN THIS PRODUCT, IN A NEW AND UNUSED CONDITION, WITH A DATED PROOF OF PURCHASE, TO THE PLACE OF PURCHASE WITHIN THIRTY (30) DAYS FROM DATE OF PURCHASE FOR A FULL REFUND. THE INSTALLATION OF THIS PRODUCT INDICATES THAT THE BUYER HAS READ AND UNDERSTANDS THIS AGREEMENT AND ACCEPTS ITS TERMS AND CONDITIONS.

#### BD Engine Brake Inc.