QUICK START GUIDE





What's in the box?

The inTune final package consists of:

1. inTune

- 4. DiabloSport USB Cable
- 2. inTune Box
- 5. inTune Quick Start Guide
- 3. DiabloSport OBD2 Cable
- 6. DiabloSport Promotional Item



Running inTune's auto update software for the first time

- 1. How to run the inTune's "auto update" software for future automatic updates.
- 2. Plug your inTune into your computer using the supplied USB cable.
- 3. If auto run settings are not currently turned on, please manually click on inTune.exe to run the update software.

NOTE: To avoid this step in the future, you can click on the check box "Always do this for software and games:."



4. If there is a update available, you will get a popup window instructing you to not unplug your inTune. Click Ok.







- Your inTune will now automatically update itself. Do not unplug your inTune until after it has rebooted.
- To access the auto update software in the future click on the inTune icon in the lower right corner of your desktop. (This icon will only appear when your inTune is plugged in).



Quick Start Guide:

Getting started:

- 1. Connect the OBD2 cable to your inTune and plug the other end into your vehicle's diagnostic port. (Check user's manual for location)
- 2. After the inTune's load screen you will be presented with 3 options:









How to tune your vehicle:

1. Select "TUNE VEHICLE" from the Main Menu.



TUNE VEHICLE

2. Select "WRITE VEHICLE" from the Tuning Menu.



WRITE VEHICLE

- 3. When prompted, turn key to "on" position without starting the
- 4. Once your vehicle is recognized, select your desired tune. (Your backup will automatically be saved)
- 5. You will be asked to confirm the selected tune. Press the green check () to confirm or red X () to go back.
- 6. You will be asked if you wish to modify the tune. Press the green check (tire sizes, gears, shift firmness, etc...) or press the red X () to skip this step.
- 7. The selected tune will now be written to your vehicle. This process can take several minutes.

How to restore your vehicle's stock factorý settings:



1. Select "TUNE VEHICLE" from the Main Menu.



TUNE VEHICLE

Tune Vehicle

2. Select "RESTORE VEHICLE" from the Tuning Menu.



3. When prompted, turn key to "on" position without starting the engine. Your original factory settings will be returned to your vehicle.

How to read /clear trouble codes:




1. Select "SCAN TOOL" from the main menu




2. Select "DTC" from the Scan Tool Menu.



DTC CODES





5. To Erase your current trouble codes select "Clear DTC's"



