

If you have any comments or concerns,  
please feel free to contact our  
customer service department at:  
Toll-free: 1-800-835-0438  
OR  
Email: info@gofia.com

SEAT COVERS  
BY



FEATURING

**SUPER-GRIP®**

**THE SLIP RESISTANT FASTENING SYSTEM**

INSTALLATION INSTRUCTIONS  
FOR

**TR42-22, Oe32-22, SP82-22**

**TR42-27, Oe32-27, SP82-27**

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

**INSTRUCTIONS:**

**A) BACKREST COVER – 60 PORTION ( X 1):**

- |                                                                                          |                                                                                                                |
|------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|
| 1) Remove head rest (see note)                                                           | 6) Attach velcro for lower seat belt opening                                                                   |
| 2) Open zipper                                                                           | 7) Install adhesive back Velcro (supplied) on inside edge of "armrest well" to align with Velcro on seat cover |
| 3) Detach Velcro for lower seat belt opening                                             | 8) Tuck flaps through crevice under backrest and attach to Velcro at back                                      |
| 4) Slip cover over backrest under seat belt. Seat cover has openings for headrest posts. | 9) Adjust velcro to equalize tension                                                                           |
| 5) Close zipper (see note)                                                               | 10) Replace headrests                                                                                          |

**B) BACKREST COVER – 40 PORTION ( X 1):**

- |                                                                         |                                                                           |
|-------------------------------------------------------------------------|---------------------------------------------------------------------------|
| 1) Remove head rest (see note)                                          | 3) Tuck flaps through crevice under backrest and attach to Velcro at back |
| 2) Slip cover over backrest. Seat cover has openings for headrest posts | 4) Adjust Velcro to equalize tension                                      |
|                                                                         | 5) Replace headrests (see note)                                           |

**C) CUSHION COVER (X 2):**


- |                                     |                                                  |
|-------------------------------------|--------------------------------------------------|
| 1) Center cover on the seat         | 3) Lift seat and attach straps to buckles        |
| 2) Pass the front straps under seat | 4) Adjust straps and buckles to equalize tension |

**D) ARMREST COVER (X 1):**

- |                 |                                              |
|-----------------|----------------------------------------------|
| 1) Open armrest | 2) Slip cover over armrest and attach Velcro |
|-----------------|----------------------------------------------|

**NOTES:**

**1) SELF-LOCKING SUPER-GRIP® BUCKLE:**




**3) ZIPPERS:**

- For ease in installation the zipper is longer than the cover.
- Tuck excess zipper under cover

**2) HEAD REST REMOVAL:**

- Insert paper clip into holes at base to release headrest from posts
- Lift off



**4) RE-INSTALLATION OF HEAD RESTS:**

- Ensure pre-cut holes in seat cover align with holes in base.
- Replace headrests

**WARNING: NEVER INSTALL SEAT COVERS ON SEATS WITH BUILT-IN AIRBAGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS WHICH COULD RESULT IN SERIOUS INJURY.**



Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438  
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com

12-5-08