

If you have any comments or concerns,
please feel free to contact our
customer service department at:
Toll-free: 1-800-835-0438
OR
Email: info@gofia.com

SEAT COVERS
BY



FEATURING

SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS

FOR

TR47-10, TR47-11, TR47-12

Oe37-10, Oe37-11, Oe37-12

SP87-10, SP87-11, SP87-12

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

The **Super Grip Buckles** are self-locking. For proper usage, see diagram.

BACKREST COVER:

- 1) Move seat to most forward position
- 2) Slip cover over backrest
- 3) Pull cover down firmly over backrest
- 4) Tuck Velcro flaps through crevice and attach to Velcro at back



NOTE: FOR SEATS WITH ARMRESTS – THE BACKREST PORTION OF THE SEAT COVER HAS VELCRO CLOSURES ON THE SIDE SEAMS TO ALLOW FOR FITTING AROUND ARMRESTS.

CUSHION COVER:

- 1) Center cover on the seat
- 2) Pass the front strap under seat and buckle to back
- 3) Pass side straps around the back of seat and buckle
- 4) Adjust all straps and buckles to equalize tension for a uniform fit

INSTALLATION ON “20” PORTION OF SEAT (TR47-10, Oe37-10, SP87-10)

CUSHION COVER:

- 1) Follow previous **CUSHION COVER** instructions

BACKREST COVER:

- 1) Open console
- 2) Center cover under armrest
- 3) Position adhesive backed Velcro to align with the Velcro on cover
- 4) Snug cover at the back of the console enough that the Velcro attached to cover is position through the crevice where the lid and console are hinged
- 5) Secure the adhesive Velcro on the inside back of console

WARNING: NEVER INSTALL SEAT COVERS ON SEATS WITH BUILT-IN AIRBAGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS WHICH COULD RESULT IN SERIOUS INJURY.



Fia Inc., Winnipeg Canada R3L 0N3 Phone: (204) 475-0515 Toll-Free: 1-800-835-0438 Fax: (204) 284-8246
E-mail: info@gofia.com Website: www.gofia.com