If you have any comments or concerns, please feel free to contact our customer service department at: Toll-free: 1-800-835-0438 OR Email: info@gofia.com

SEAT COVERS

FEATURING

SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS FOR TR47-21, TR47-22 OE37-21, OE37-22 SP87-21, SP87-22

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

INSTRUCTIONS:

A) BACKREST COVER – TR7-21, OE37-21, SP87-21

1. move seat to most forward position

2. center cover over backrest and install under seat belt

3. smooth cover from top to bottom

- 4) place cover so side latch is through hole provide in seat cover
- 5) insert flaps through crevice and attach to velcro at back

B) BACKREST COVER – TR47-22, OE37-22, SP87-22

 move seat to most forward position
with armrest in down position, center cover over backrest and install under seat belt
smooth cover from top to bottom

4) secure velcro on the inside of armrest well

4) place cover so side latch is through hole provide in seat cover

5) insert flaps through crevice and attach to velcro at back

C) ARMREST COVER – TR47-22, OE37-22, SP87-22

1) slip cover over armrest

2) attach velcro

D) CUSHION COVER

 center cover on the seat
position the seat belts through the opening provided. Driver side has velcro opening
tuck back flap through the seat crevice 4) pass the front straps under the seat and secure to buckles(see note)5) attach side velcro on to carpeting on back of seat cushion

NOTES:

1) SELF-LOCKING SUPER-GRIP® BUCKLE:



WARNING: NEVER INSTALL SEAT COVERS ON SEATS WITH BUILT-IN AIRBAGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS WHICH COULD RESULT IN SERIOUS INJURY.



Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438 Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com