If you have any comments or concerns, please feel free to contact our customer service department at: Toll-free: 1-800-835-0438 OR Email: info@gofia.com SEAT COVERS



FEATURING

SUPER-GRIP® THE SLIP RESISTANT FASTENING SYSTEM INSTALLATION INSTRUCTIONS

> FOR OE37-37

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

A) BACKREST COVER

INSTRUCTIONS:

- 1) Remove headrests (see note)
- 2) Open velcro on the side seam to allow for fitting around armrest
- 3) Slip cover over backrest and pull down firmly (see air bag warning below)
- 4) Fasten side velcro

back 6) Adjust all velcro to equalize tension

4) Adjust straps and buckles to equalize tension

5) Tuck flaps through crevice and attached to velcro at

7) Replace headrests (see note)

B) CUSHION COVER

1) Center cushion cover on seat

2) Pass the front strap under the seat and buckle to the back flap of cover

3) Pass side strap on narrow side band through the opening between the molded plastic and the seat (door side) and buckle to other side of cover

NOTES:

1) SELF-LOCKING SUPER-GRIP® BUCKLE:




3) RE-INSTALLATION OF HEADRESTS

- A) Ensure pre-cut holes in seat cover align with holes in base.
- B) Replace headrests

2) HEAD REST REMOVAL:

Push in side release buttons - Lift off (If unable to remove consult dealership)



WARNING: DO NOT BLOCK AIR BAGS

WHEN INSTALLING SEAT COVERS:

1) Seats with integrated seat airbags must be covered only with seat covers designed with openings. Make sure that the openings in the sides of the seat covers are positioned so that the seat covers do not block or interfere with the deployment of the air bag. The attached flap tucks inside the cutout and should be able to open freely in case of deployment.

2) Constantly check your seat covers to ensure they are properly positioned to allow for complete air bag deployment.

LIMITATION LIABILITY:

The manufacturer shall not be liable for any damages or for the breach of any warranty, express or implied, whether of merchantability or fitness for any purpose or otherwise, or for any other obligation or liability arising out of the installation of the seat covers or the movement of the seat covers after installation.

fia

Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438 Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com