

If you have any comments or concerns,
please feel free to contact our
customer service department at:
Toll-free: 1-800-835-0438
OR
Email: info@gofia.com

SEAT COVERS
BY



FEATURING

SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS

FOR

TR48-15, TR48-16, TR48-17

Oe38-15, Oe38-16, Oe38-17

SP88-15, SP88-16, SP88-17

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

A) BACKREST COVER – BUCKETS / “40” PORTION X 2:

- | | |
|---|---|
| 1) Remove head rest (see note) | 5) Tuck flaps under backrest and attach to Velcro at back |
| 2) Open zipper | 6) Adjust Velcro to equalize tension |
| 3) Slip cover over backrest under seat belt | 7) Replace headrests (see note) |
| 4) Close zipper (see note) | |

B) CUSHION COVER - BUCKETS / “40” PORTION X 2:

- | | |
|--|--|
| 1) Center cover on the seat | 3) Pass side straps around back of seat and buckle |
| 2) Pass the front strap under seat and buckle to back flap | 4) Adjust straps and buckles to equalize tension |

- 1) Repeat “B)”

D) BACKREST COVER – CENTER “20” PORTION X 1

For models TR48-16, Oe38-16, SP88-16

- | | |
|---|---|
| 1) Open console | 4) Snug cover at back of console so the Velcro on the cover meets the hinge |
| 2) Center cover under armrest | 5) Secure the adhesive back Velcro inside the console |
| 3) Position adhesive back Velcro (supplied) to align with the Velcro on side of cover | |

For models TR48-17, Oe38-17, SP88-17

- 1) Slip cover over backrest and attach Velcro

NOTES:

1) SELF-LOCKING SUPER-GRIP® BUCKLE:




2) HEAD REST REMOVAL:

- A) - Insert paper clip into holes at base to release
- Lift off

OR

- B) - Push in side release buttons
- Lift off

(If unable to remove consult dealership)



3) SEATS WITH SIDE ARMRESTS:

- Locate opening in stretch fabric
- Slip armrest through opening

4) ZIPPERS:

- For ease in installation the zipper is longer than the cover.
- Tuck excess zipper under cover

5) RE-INSTALLATION OF HEADRESTS

- A) Ensure pre-cut holes in seat cover align with holes in base.
B) Replace headrests

WARNING: NEVER INSTALL SEAT COVERS ON SEATS WITH BUILT-IN AIRBAGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS WHICH COULD RESULT IN SERIOUS INJURY.



Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com

04-28-08