

If you have any comments or concerns,
please feel free to contact our
customer service department at:
Toll-free: 1-800-835-0438
OR
Email: info@gofia.com

SEAT COVERS
BY



FEATURING

SUPER-GRIP[®]

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS
FOR
TR42-18, Oe32-18, SP82-18, SL62-18

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

INSTRUCTIONS:

A) BACKREST COVER

- 1) Starting with the top left corner of the seat, install cover by attaching velcro to carpeting on back of seat
- 2) Smooth cover tightly from top to bottom
- 3) Tuck stretch fabric at bottom of cover through crevice and behind backrest. For easier access raise seat cushion and hold in $\frac{3}{4}$ up position
- 4) Smooth cover tightly on both sides and attach velcro on to carpeting
- 5) Tuck stretch fabric around top and sides of seat to cover up the velcro

B) CUSHION COVERS

- 1) Center cover on seat
- 2) While holding cushion in $\frac{3}{4}$ up position, tuck back flap through crevice
- 3) Pass the front strap under cushion and buckle to back flap
- 4) Pass side straps around the back of seat and buckle
- 5) Adjust straps and buckles to equalize tension

NOTES:

- 1) SELF-LOCKING SUPER-GRIP[®] BUCKLE:



WARNING: NEVER INSTALL SEAT COVERS ON SEATS WITH BUILT-IN AIRBAGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS WHICH COULD RESULT IN SERIOUS INJURY.



Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com

4-28-08