

If you have any comments or concerns,
please feel free to contact our
customer service department at:
Toll-free: 1-800-835-0438
OR
Email: info@gofia.com

SEAT COVERS
BY



FEATURING

SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS
FOR

**TR42-22, Oe32-22, SL62-22, SP82-22
TR42-27, Oe32-27, SL62-27, SP82-27**

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

INSTRUCTIONS:

A) BACKREST COVER – 60 PORTION (X 1):

- | | |
|--|--|
| 1) Remove head rest (see note) | 6) Attach velcro for lower seat belt opening |
| 2) Open zipper | 7) Install adhesive back Velcro (supplied) on inside edge of "armrest well" to align with Velcro on seat cover |
| 3) Detach Velcro for lower seat belt opening | 8) Tuck flaps through crevice under backrest and attach to Velcro at back |
| 4) Slip cover over backrest under seat belt. Seat cover has openings for headrest posts. | 9) Adjust velcro to equalize tension |
| 5) Close zipper (see note) | 10) Replace headrests |

B) BACKREST COVER – 40 PORTION (X 1):

- | | |
|---|---|
| 1) Remove head rest (see note) | 3) Tuck flaps through crevice under backrest and attach to Velcro at back |
| 2) Slip cover over backrest. Seat cover has openings for headrest posts | 4) Adjust Velcro to equalize tension |
| | 5) Replace headrests (see note) |

C) CUSHION COVER (X 2):


- | | |
|-------------------------------------|--|
| 1) Center cover on the seat | 3) Lift seat and attach straps to buckles |
| 2) Pass the front straps under seat | 4) Adjust straps and buckles to equalize tension |

D) ARMREST COVER (X 1):

- | | |
|-----------------|--|
| 1) Open armrest | 2) Slip cover over armrest and attach Velcro |
|-----------------|--|


NOTES:

1)SELF-LOCKING SUPER-GRIP® BUCKLE:



2) HEAD REST REMOVAL:

- Insert paper clip into holes at base to release headrest from posts
- Lift off



3) ZIPPERS:

- For ease in installation the zipper is longer than the cover.
- Tuck excess zipper under cover

4) RE-INSTALLATION OF HEAD RESTS:

- Ensure pre-cut holes in seat cover align with holes in base.
- Replace headrests

WARNING: NEVER INSTALL SEAT COVERS ON SEATS WITH BUILT-IN AIRBAGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS WHICH COULD RESULT IN SERIOUS INJURY.



Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com

12-5-08