

If you have any comments or concerns,
please feel free to contact our
customer service department at:
Toll-free: 1-800-835-0438
OR
Email: info@gofia.com


SEAT COVERS
BY



FEATURING

SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM



INSTALLATION INSTRUCTIONS
FOR
SL62-98

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

A) BACKREST COVER 40 side:

- | | |
|--|---|
| 1) Unlatch backrest from back wall | 5) Fold down backrest and attach flaps on velcro at back of cover |
| 2) Remove headrests (see note below) | 6) Re-latch backrest to back wall |
| 3) Slip cover over backrest | 7) Replace headrests (see notes) |
| 4) Tuck flaps through crevice under backrest | |

B) BACKREST COVER 60 side:

- | | |
|--|---|
| 1) Unlatch backrest from back wall | 5) Place armrest in down position and reattach velcro on cover |
| 2) Remove headrests (see note below) | 6) Tuck flaps through crevice under backrest |
| 3) Detach velcro on cover | 7) Fold down backrest and attach flaps on velcro at back of cover |
| 4) Slip cover over backrest under center seat belt positioning armrest through opening | 8) Re-latch backrest to back wall |
| | 9) Replace headrests (see notes) |

C) ARMREST COVER

- | | |
|----------------------|--|
| 1) Fold armrest down | 2) Slip cover over armrest and attach velcro |
|----------------------|--|

D) CUSHION COVERS X 2:

- | | |
|---|---|
| 1) Center cover on seat | 4) Lift seat in up position and buckle straps |
| 2) Tuck back of seat cover into crevice | 5) Adjust straps and buckle to equalize tension |
| 3) Ensure the slit is in line with car seat hook up | |


NOTES:

1) SELF-LOCKING SUPER-GRIP® BUCKLE:



2) HEAD REST REMOVAL:

- Push in side release buttons
 - Lift off
- (If unable to remove consult dealership)



3) RE-INSTALLATION OF HEADRESTS

- A) Ensure pre-cut holes in seat cover align with holes in headrest base.
B) Replace headrests

WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.



Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com

10-14-15