

If you have any comments or concerns,
please feel free to contact our
customer service department at:
Toll-free: 1-800-835-0438
OR
Email: info@gofia.com

SEAT COVERS
BY



FEATURING

SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS
FOR

TR49-13

Oe39-13

SL69-13

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

INSTRUCTIONS:

BACKREST COVERS

- | | |
|--|---|
| 1) Remove head rest (see note) | 3) Tuck flaps under backrest and attach to Velcro at back |
| 2) Slip cover over backrest. Ensure latch opening in seat cover is on the inner side of the seat (facing other bucket) | 4) Adjust Velcro to equalize tension |
| | 5) Replace headrests (see note) |

CUSHION COVERS

- | | |
|--|--|
| 1) Center cover on the seat | 4) Adjust straps and buckles to equalize tension |
| 2) Pass the front strap under seat. Buckle to back flap | |
| 3) Pass side straps through the opening between the molded plastic and the seat. Buckle to back flap | |

NOTES:

1) SELF-LOCKING SUPER-GRIP® BUCKLE:



3) RE-INSTALLATION OF HEADRESTS

- Locate headrest base and put a small slit in the stretch fabric to accommodate each of the posts
- Stretch fabric will not run
- Replace headrests


2) HEAD REST REMOVAL:

- A) - Insert paper clip into holes at base to release
- Lift off

OR

- B) - Push in side release buttons
- Lift off

(If unable to remove consult dealership)



WARNING: NEVER INSTALL SEAT COVERS ON SEATS WITH BUILT-IN AIRBAGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS WHICH COULD RESULT IN SERIOUS INJURY.



Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com