

If you have any comments or concerns,
please feel free to contact our
customer service department at:
Toll-free: 1-800-835-0438
OR
Email: info@gofia.com

SEAT COVERS
BY



FEATURING

SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS
FOR

TR49-72, Oe39-72, SP89-72, SL69-72

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

A) CUSHION COVER:

- 1) Center cover on the seat with the bigger opening on the door side.
- 2) Position seat lever through bigger opening and seat belt buckle through other opening.
- 3) Pass the side velcro to back and attach to carpet on cover
- 4) Pass the front strap under seat. Buckle to back flap of cover
- 5) Buckle side straps to back flap of cover
- 6) Adjust straps and buckles to equalize tension

B) BACKREST COVER:

- 1) Pull cover down over backrest. Cover has allowance for lever
- 2) With backrest folded forward, tuck in velcro pieces on crevice and attach to carpeting on cushion cover
- 3) Stretch fabric has velcro to attach on carpeting on the back flap of seat
- 4) Adjust all velcro to equalize tension for a uniform fit

NOTES:

1) SELF-LOCKING SUPER-GRIP® BUCKLE:



WARNING: NEVER INSTALL SEAT COVERS ON SEATS WITH BUILT-IN AIRBAGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS WHICH COULD RESULT IN SERIOUS INJURY.



Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com