



11147640

6 Pole Round to 12VDV Inverter Adapter

This adapter is to be used on a 12 Volt DC system only. Adapter should be connected to a power inverter prior to plugging into a vehicle connector.

1. Attach the White wire to the “Negative” lead on a power inverter.
2. Attach the Black wire to the “Positive” lead on a power inverter.
3. Plug the adapter into the tow vehicle connector.

Maximum current draw from the vehicle should not exceed 25 amp.

Caution: If the ring terminals are not attached to the correct positive & negative power inverter terminals, damage may occur to the power inverter or the vehicle's electrical system.

Note: Power draw from the vehicle battery will occur. The vehicle should be started & ran periodically to recharge the vehicle battery. Some vehicles may require the ignition switch to be turned to the auxiliary position to activate the power source.

6 Polos Redondo del Inversor

Este adaptador solamente se usa en sistemas de 12 voltos. El adaptador deberá de ser conectado al inversor de poder antes de acoplar al conector del vehículo


1. Fije el cable Blanco a la terminal “negativa” del inversor de poder
2. Fije el cable Negro a la terminal positiva del inversor de poder
3. Conecte en adaptador en el conector del vehículo

La máxima corriente suministrada por el vehículo no deberá exceder 25 amperes.

Precaución: Si las terminales de ojo, no están correctamente conectadas a las terminales positivas y negativas de inversor de poder, este, o el sistema eléctrico del vehículo se podrían dañar.

Nota: Corriente va a ser suministrada por el vehículo. El vehículo deberá de ser puesto en marcha periódicamente para recargar la batería. Algunos vehículos requieren que la llave de encendido se posicione en auxiliar para activar la fuente de poder.

Wiring Diagram



WIRE IDENTIFICATION / IDENTIFICACIÓN DE LOS CABLES	
(GD)	= Ground / Tierra / Masse
(LT)	= Left Turn / Direccional Izquierda / Clignotant gauche
(TM)	= Taillight / Luces traseras / Feu arrière
(A)	= Auxiliary / Auxiliar / Auxiliaire
(RT)	= Right Turn / Direccional Derecha / Clignotant droit
(S)	= Electric Brake / Eléctrico del freno / Électrique de frein

Need Help? (English Only)

1-800-835-0129

techsupport@hopkinsmfg.com

www.hopkinstowsingsolutions.com