

SPRING REPLACEMENT KIT

Fits Pro-Matic 2 & V-Matic 2 **Automatic Shifters**

INSTALLATION INSTRUCTIONS

Shifter Spring Part Number # 1174826

1. Remove cover or consule from shifter.

2. Make sure the shifter is in the neutral position.

3. Mark the location of the old spring assembly with a pencil.

4. Use a torx head screwdriver to remove the (4) screws holding the spring assembly to the shift.

5. Remove the old spring assembly.

6. Install the new spring assembly by spreading the spring ends around the shifter pin.

7. Align the new spring assembly with the pencil marks.

8. Replace the (4) screws into the spring assembly and tighten.

9. Replace the console or cover.

Shifter Spring Part Number # 97093063

1. Remove cover or console from shifter.

2. Make sure the shifter is in the neutral position.

3. Use outer "C" clip pliers to remove the "C" clip.

4. Slide off washer and nylon sleeve.

5. Slide off spring.

6. Insert the nylon sleeve into the spring.

7. Slide on new spring with sleeve installed on to the shaft with either end straddling the shifter stick.

8. Slide on washer.

Replace "C" clip.
Replace the console or cover.

Shifter Spring Part Number # 97093217 (V-Matic only)

1. Remove cover or console from shifter.


2. Make sure the shifter is in the neutral position.

3. Use small bladed screwdriver to remove the "C" clip.


4. Slide off old hairpin spring.

5. Slide on new hairpin spring.

6. Replace the console or cover.



Pro-Matic



V-Matic