

# 71-1004 INSTRUCTIONS



## APPLICATIONS

### HYUNDAI

Accent	2006-2008
Azera	2006-2007
Elantra	2007-2008
Entourage	2007
Veracruz	2007-2008

### KIA

Optima	2006.5 – 2007
Rio	2006-2007
Rondo	2007
Sedona	2006-2007
Sorento	2007
Spectra	2007
Spectra 5	2007
Sportage	2005-2007

1-800-221-0932

[www.metraonline.com](http://www.metraonline.com)

© COPYRIGHT 2008 METRA ELECTRONICS CORPORATION

# 71-1004 INSTRUCTIONS



## APPLICATIONS

### HYUNDAI

Accent	2006-2008
Azera	2006-2007
Elantra	2007-2008
Entourage	2007
Veracruz	2007-2008

### KIA

Optima	2006.5 – 2007
Rio	2006-2007
Rondo	2007
Sedona	2006-2007
Sorento	2007
Spectra	2007
Spectra 5	2007
Sportage	2005-2007

1-800-221-0932

[www.metraonline.com](http://www.metraonline.com)

© COPYRIGHT 2008 METRA ELECTRONICS CORPORATION

# 71-1004 INSTRUCTIONS



## APPLICATIONS

### HYUNDAI

Accent	2006-2008
Azera	2006-2007
Elantra	2007-2008
Entourage	2007
Veracruz	2007-2008

### KIA

Optima	2006.5 – 2007
Rio	2006-2007
Rondo	2007
Sedona	2006-2007
Sorento	2007
Spectra	2007
Spectra 5	2007
Sportage	2005-2007

1-800-221-0932

[www.metraonline.com](http://www.metraonline.com)

© COPYRIGHT 2008 METRA ELECTRONICS CORPORATION

# 71-1004 INSTRUCTIONS



## APPLICATIONS

### HYUNDAI

Accent	2006-2008
Azera	2006-2007
Elantra	2007-2008
Entourage	2007
Veracruz	2007-2008

### KIA

Optima	2006.5 – 2007
Rio	2006-2007
Rondo	2007
Sedona	2006-2007
Sorento	2007
Spectra	2007
Spectra 5	2007
Sportage	2005-2007

1-800-221-0932

[www.metraonline.com](http://www.metraonline.com)

© COPYRIGHT 2008 METRA ELECTRONICS CORPORATION

# 71-1004 INSTRUCTIONS



## 24 WAY CONNECTOR

Pin	Color	Function
1	Yellow	12V Battery/Memory
2	Red	12 Volt Switched/Accessory
3	Blue/White	Amplifier Turn On
4	Black/White	Right (+) Aux In
5	Blue/Black	Aux In Signal Ground
6	Gray/Brown	Rear Arm Remote Control
7	Green/White	Steering Wheel Control
8	Orange	Illumination
9	Green	Left Rear (+) Speaker
10	Purple	Right Rear (+) Speaker
11	Gray	Right Front (+) Speaker
12	White	Left Front (+) Speaker
13	Black	Ground
14	Blue	Antenna Turn On
15	Red/White	Surround On/Off
16	White/Blue	Left Aux In (+)
17	White/Red	EQ Sel/Aux In Common (-)
18	Yellow/Black	Tele Mute
19	Yellow/Red	Steering Wheel Control Reference Ground
20	Black/Yellow	Illumination (-)
21	Green/Black	Left Rear (-) Speaker
22	Purple/Black	Right Rear (-) Speaker
23	Gray/Black	Right Front (-) Speaker
24	White/Black	Left Front (-) Speaker

Rev. 04/14/08

INST71-1004

# 71-1004 INSTRUCTIONS



## 24 WAY CONNECTOR

Pin	Color	Function
1	Yellow	12V Battery/Memory
2	Red	12 Volt Switched/Accessory
3	Blue/White	Amplifier Turn On
4	Black/White	Right (+) Aux In
5	Blue/Black	Aux In Signal Ground
6	Gray/Brown	Rear Arm Remote Control
7	Green/White	Steering Wheel Control
8	Orange	Illumination
9	Green	Left Rear (+) Speaker
10	Purple	Right Rear (+) Speaker
11	Gray	Right Front (+) Speaker
12	White	Left Front (+) Speaker
13	Black	Ground
14	Blue	Antenna Turn On
15	Red/White	Surround On/Off
16	White/Blue	Left Aux In (+)
17	White/Red	EQ Sel/Aux In Common (-)
18	Yellow/Black	Tele Mute
19	Yellow/Red	Steering Wheel Control Reference Ground
20	Black/Yellow	Illumination (-)
21	Green/Black	Left Rear (-) Speaker
22	Purple/Black	Right Rear (-) Speaker
23	Gray/Black	Right Front (-) Speaker
24	White/Black	Left Front (-) Speaker

Rev. 04/14/08

INST71-1004

# 71-1004 INSTRUCTIONS



## 24 WAY CONNECTOR

Pin	Color	Function
1	Yellow	12V Battery/Memory
2	Red	12 Volt Switched/Accessory
3	Blue/White	Amplifier Turn On
4	Black/White	Right (+) Aux In
5	Blue/Black	Aux In Signal Ground
6	Gray/Brown	Rear Arm Remote Control
7	Green/White	Steering Wheel Control
8	Orange	Illumination
9	Green	Left Rear (+) Speaker
10	Purple	Right Rear (+) Speaker
11	Gray	Right Front (+) Speaker
12	White	Left Front (+) Speaker
13	Black	Ground
14	Blue	Antenna Turn On
15	Red/White	Surround On/Off
16	White/Blue	Left Aux In (+)
17	White/Red	EQ Sel/Aux In Common (-)
18	Yellow/Black	Tele Mute
19	Yellow/Red	Steering Wheel Control Reference Ground
20	Black/Yellow	Illumination (-)
21	Green/Black	Left Rear (-) Speaker
22	Purple/Black	Right Rear (-) Speaker
23	Gray/Black	Right Front (-) Speaker
24	White/Black	Left Front (-) Speaker

Rev. 04/14/08

INST71-1004

# 71-1004 INSTRUCTIONS



## 24 WAY CONNECTOR

Pin	Color	Function
1	Yellow	12V Battery/Memory
2	Red	12 Volt Switched/Accessory
3	Blue/White	Amplifier Turn On
4	Black/White	Right (+) Aux In
5	Blue/Black	Aux In Signal Ground
6	Gray/Brown	Rear Arm Remote Control
7	Green/White	Steering Wheel Control
8	Orange	Illumination
9	Green	Left Rear (+) Speaker
10	Purple	Right Rear (+) Speaker
11	Gray	Right Front (+) Speaker
12	White	Left Front (+) Speaker
13	Black	Ground
14	Blue	Antenna Turn On
15	Red/White	Surround On/Off
16	White/Blue	Left Aux In (+)
17	White/Red	EQ Sel/Aux In Common (-)
18	Yellow/Black	Tele Mute
19	Yellow/Red	Steering Wheel Control Reference Ground
20	Black/Yellow	Illumination (-)
21	Green/Black	Left Rear (-) Speaker
22	Purple/Black	Right Rear (-) Speaker
23	Gray/Black	Right Front (-) Speaker
24	White/Black	Left Front (-) Speaker

Rev. 04/14/08

INST71-1004