



71-7552 INSTRUCTIONS

2007-2009 NISSAN (excluding Navigational models)
HARNESS INTO FACTORY RADIO

APPLICATIONS

NISSAN

ALTIMA 2007-2009
ARMADA 2008-2009
FRONTIER 2009
MAXIMA 2007-2009
MURANO (NON-BOSE) 2009
PATHFINDER 2008-2009
ROGUE 2008
SENTRA 2007-2008
VERSA 2007-2009
370 Z 2009

SUBARU

(Without factory navigation)

FORESTER 2009
IMPREZA/WRX 2008

1-800-221-0932

www.metraonline.com

© COPYRIGHT 2004-2009 METRA ELECTRONICS CORPORATION



71-7552 INSTRUCTIONS

2007-2009 NISSAN (excluding Navigational models)
HARNESS INTO FACTORY RADIO

APPLICATIONS

NISSAN

ALTIMA 2007-2009
ARMADA 2008-2009
FRONTIER 2009
MAXIMA 2007-2009
MURANO (NON-BOSE) 2009
PATHFINDER 2008-2009
ROGUE 2008
SENTRA 2007-2008
VERSA 2007-2009
370 Z 2009

SUBARU

(Without factory navigation)

FORESTER 2009
IMPREZA/WRX 2008

1-800-221-0932

www.metraonline.com

© COPYRIGHT 2004-2009 METRA ELECTRONICS CORPORATION



71-7552 INSTRUCTIONS

2007-2009 NISSAN (excluding Navigational models)
HARNESS INTO FACTORY RADIO

APPLICATIONS

NISSAN

ALTIMA 2007-2009
ARMADA 2008-2009
FRONTIER 2009
MAXIMA 2007-2009
MURANO (NON-BOSE) 2009
PATHFINDER 2008-2009
ROGUE 2008
SENTRA 2007-2008
VERSA 2007-2009
370 Z 2009

SUBARU

(Without factory navigation)

FORESTER 2009
IMPREZA/WRX 2008

1-800-221-0932

www.metraonline.com

© COPYRIGHT 2004-2009 METRA ELECTRONICS CORPORATION



71-7552 INSTRUCTIONS

2007-2009 NISSAN (excluding Navigational models)
HARNESS INTO FACTORY RADIO

APPLICATIONS

NISSAN

ALTIMA 2007-2009
ARMADA 2008-2009
FRONTIER 2009
MAXIMA 2007-2009
MURANO (NON-BOSE) 2009
PATHFINDER 2008-2009
ROGUE 2008
SENTRA 2007-2008
VERSA 2007-2009
370 Z 2009

SUBARU

(Without factory navigation)

FORESTER 2009
IMPREZA/WRX 2008

1-800-221-0932

www.metraonline.com

© COPYRIGHT 2004-2009 METRA ELECTRONICS CORPORATION

Pin	Color	Function
1	blue/white	amplifier turn on (amplified models only)
2	white	left front speaker (+) (left front input (+) amplified models)
3	white/black	left front speaker (-) (left front input (-) amplified models)
4	green	left rear speaker (+) (left rear input (+) amplified models)
5	green/black	left rear speaker (-) (left rear input (-) amplified models)
6	brown/blue	steering wheel control A (up)
7	red	12 volt accessory
8	orange/black	illumination (-)
9	orange	illumination (+)
10	black/yellow	signal ground (amplified models)
11	gray	right front speaker (+) (right front input (+) amplified models)
12	gray/black	right front speaker (-) (right front Input (-) amplified models)
13	violet	right rear speaker (+) (right rear input(+)) amplified models)
14	violet/black	right rear speaker (-) (right rear input (-) amplified models)
15	black/gray	steering wheel control C (ground reference)
16	brown/black	steering wheel control B (down)
17	open	
18	open	
19	yellow	12 volt constant
20	black	ground (Subaru only)

Rev. 04/02/09

INST71-7552

Pin	Color	Function
1	blue/white	amplifier turn on (amplified models only)
2	white	left front speaker (+) (left front input (+) amplified models)
3	white/black	left front speaker (-) (left front input (-) amplified models)
4	green	left rear speaker (+) (left rear input (+) amplified models)
5	green/black	left rear speaker (-) (left rear input (-) amplified models)
6	brown/blue	steering wheel control A (up)
7	red	12 volt accessory
8	orange/black	illumination (-)
9	orange	illumination (+)
10	black/yellow	signal ground (amplified models)
11	gray	right front speaker (+) (right front input (+) amplified models)
12	gray/black	right front speaker (-) (right front Input (-) amplified models)
13	violet	right rear speaker (+) (right rear input(+)) amplified models)
14	violet/black	right rear speaker (-) (right rear input (-) amplified models)
15	black/gray	steering wheel control C (ground reference)
16	brown/black	steering wheel control B (down)
17	open	
18	open	
19	yellow	12 volt constant
20	black	ground (Subaru only)

Rev. 04/02/09

INST71-7552

Pin	Color	Function
1	blue/white	amplifier turn on (amplified models only)
2	white	left front speaker (+) (left front input (+) amplified models)
3	white/black	left front speaker (-) (left front input (-) amplified models)
4	green	left rear speaker (+) (left rear input (+) amplified models)
5	green/black	left rear speaker (-) (left rear input (-) amplified models)
6	brown/blue	steering wheel control A (up)
7	red	12 volt accessory
8	orange/black	illumination (-)
9	orange	illumination (+)
10	black/yellow	signal ground (amplified models)
11	gray	right front speaker (+) (right front input (+) amplified models)
12	gray/black	right front speaker (-) (right front Input (-) amplified models)
13	violet	right rear speaker (+) (right rear input(+)) amplified models)
14	violet/black	right rear speaker (-) (right rear input (-) amplified models)
15	black/gray	steering wheel control C (ground reference)
16	brown/black	steering wheel control B (down)
17	open	
18	open	
19	yellow	12 volt constant
20	black	ground (Subaru only)

Rev. 04/02/09

INST71-7552

Pin	Color	Function
1	blue/white	amplifier turn on (amplified models only)
2	white	left front speaker (+) (left front input (+) amplified models)
3	white/black	left front speaker (-) (left front input (-) amplified models)
4	green	left rear speaker (+) (left rear input (+) amplified models)
5	green/black	left rear speaker (-) (left rear input (-) amplified models)
6	brown/blue	steering wheel control A (up)
7	red	12 volt accessory
8	orange/black	illumination (-)
9	orange	illumination (+)
10	black/yellow	signal ground (amplified models)
11	gray	right front speaker (+) (right front input (+) amplified models)
12	gray/black	right front speaker (-) (right front Input (-) amplified models)
13	violet	right rear speaker (+) (right rear input(+)) amplified models)
14	violet/black	right rear speaker (-) (right rear input (-) amplified models)
15	black/gray	steering wheel control C (ground reference)
16	brown/black	steering wheel control B (down)
17	open	
18	open	
19	yellow	12 volt constant
20	black	ground (Subaru only)

Rev. 04/02/09

INST71-7552