

MSD IGNITION INSTALLATION INSTRUCTIONS

RPM MODULE SELECTOR SWITCH

PN 8670	3,000 - 5,200 RPM
PN 8671	4,600 - 6,800 RPM
PN 8672	6,000 - 8,200 RPM
PN 8673	7,600 - 9,200 RPM
PN 8674	9,000 - 11,200 RPM
PN 8675	10,600 - 12,800 RPM

Parts Included:

- 1 - RPM Module Selector Switch
- 4 - Mounting Screws

Mount the Switch close to the MSD Ignition in a position so it is accessible and easy to read. **The wires of the Switch cannot be lengthened.** Use the supplied mounting screws or the adhesive on the back panel of the unit to mount the Switch.

The 2-pin connector of the Switch plugs into the rpm module receptacle of the MSD component. There is no polarity so its position does not make a difference.




Figure 1 RPM Module Selector Installation.

