

# INSTALLATION INSTRUCTIONS ATV WINCH MOUNT

Mount Kit: PN 28878

**Application: HONDA TRX 300, 4X4** 

As you read these instructions, you will see **NOTES**, **CAUTIONS** and **WARNINGS**. Each message has a specific purpose. **NOTES** are additional information to help you complete a procedure. **CAUTIONS** are safety messages that indicate a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. A **CAUTION** may also be used to alert against unsafe practice or possible equipment damage. **WARNINGS** are safety messages that indicate a potentially hazardous situation, which, if not avoided could result in serious injury. **CAUTIONS** and **WARNINGS** identify the hazard, indicate how to avoid the hazard, and advise of the probable consequence of not avoiding the hazard. **PLEASE WORK SAFELY!** 

### **WARNING**

## SEVERE INJURY OR DEATH MAY RESULT IF YOU IGNORE ANY OF THE FOLLOWING.

- Read the Winch Operator's Manual, ATV Operator's Manual, and all warning labels before operating the winch and ATV.
- Stay clear of moving parts and cable. Keep others away when operating the winch.
- Inspect the winch mechanism, fasteners, and cable, before operating. Replace all worn or damaged parts before operating.
- Make sure the winch is deactivated when leaving the ATV unattended.


### PARTS LIST:

PART NO.	<b>QUANTITY</b>	<b>DESCRIPTION</b>
39424	1	Winch mounting plate
39423	1	Bracket support, right
39422	1	Bracket support, left
38917	2	Support bracket
37524	4	5/16-18
2583	2	7/16-14 Hex Nut
2146	2	7/16 Lock Washer
22513	2	3/8-16 x 2 ½ Hex Bolt
1828	2	3/8-16 Hex Nut
1829	2	3/8 Lock Washer
2008	2	<sup>1</sup> / <sub>4</sub> -20 x 2 Hex Bolt
1322	2	<sup>1</sup> / <sub>4</sub> -20 Hex Nut
1321	2	1/4 Lock Washer

WARN INDUSTRIES PAGE 1 39445 Rev A0

#### **INSTRUCTIONS:**

- 1. Place winch directly to mounting plate without using the combination mounting plate/fairlead supplied with the winch. Looking at the ATV from the front, the winch motor would be on the left side of ATV and drum rotation arrow will be facing forward, as pictured. Attach winch to mounting plate using (4) 5/16 x 1 hex bolts and lock washers supplied with winch. Tighten bolts securely.
- 2. Place winch and mounting plate into frame as pictured.
- 3. Fasten rear of mounting plate using (2) 1" U-clamps (2) 3/8 x 2 hex bolts and (2) 3/8 hex nuts and lock washers.
- 4. Fasten front of mounting plate using (2) ¾ U-clamps (2) ¼-20 x 1 ¾ hex bolts and (2) ¼-20 hex nuts and lock washers.
- 5. Fasten cast hawse fairlead to front tube assembly as pictured, using (2) 1" x 1 ¾ U-clamps, (2) 7/16-14 x 2 ¼ hex bolts and (2) 7/16-14 hex nuts and lock washers.
- 6. Make electrical connections using manual supplied with winch.



WARN INDUSTRIES PAGE 2 39445 Rev A0