

“STOP”

This clutch assembly requires replacement of the Hydraulic Slave Cylinder and Release Bearing assembly. Please read the enclosed instruction sheet or contact Centerforce for more information before proceeding.

Thank You!