

INSTALLATION MANUAL

52216

Level of Difficulty

Easy

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

Parts List

Item	Qty	Description
1	1	Battery Disconnect

Tools Required

Box-end wrench set | Wire brush

* For a tools reference guide visit curtmfg.com/trailer-hitch-installation

⚠ CAUTION

Failure to connect the Towed Battery Disconnect according to the instructions may result in damage to your battery or other electronics, in which CURT is not responsible.

Product Photo



NOTICE

Visit www.curtmfg.com for a full-color copy of this instruction manual, as well as helpful videos, guides and much more!

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

Periodic inspection of the trailer hitch should be performed to ensure all mounting hardware remains tight and structural components are secure.

To help prevent damage to the product or vehicle, refer to the specified torque specifications when securing hardware during the installation process.

SAFETY INSTRUCTIONS

Safety glasses should be worn at all times while installing this product.

Product Registration and Warranty

CURT stands behind our products with industry-leading warranties. To get copies of the product warranties, register your purchase or provide feedback, visit: warranty.curtgroup.com/surveys

Step 1

Make sure the engine is completely off and the key removed from the tow vehicle.

NOTICE

Do not attempt to install the Towed Battery Disconnect with the engine running.

Find the correct wrench to loosen the negative cable connector on the battery of the tow vehicle. Remove the cable from the negative battery post. Clean battery negative post/side terminal with a wire brush.



Step 2

Install the negative cable connector to the Battery Disconnect and tighten.



Step 3

Connect the negative end of the Battery Disconnect to the negative battery terminal and tighten the nut.



Step 4

To connect or disconnect the battery, turn the knob on the Battery Disconnect accordingly.

NOTICE

Disconnect Battery Power with one counterclockwise turn of the knob. Do not attempt to pull the two halves of this assembly apart.

