


If you have any comments or concerns,  
 please feel free to contact our  
 customer service department at:  
 Toll-free: 1-800-835-0438  
 OR  
 Email: info@gofia.com

SEAT COVERS  
 BY



FEATURING

**SUPER-GRIP®**

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS  
 FOR

NP92-16/ Oe32-16/ SL62-16/ SP82-16/ TR42-16/ TRS42-16

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

**INSTRUCTIONS:**

1. Remove seat belt buckles from holder on cushion
2. Center cover on seat
3. Slip seat belt buckles through elastics on seat covers
4. Lift cushion halfway to up position

**A) CUSHION COVERS:**







5. Insert strap through crevice and buckle
6. Attach velcro to carpet on underside of cushion
7. Adjust all straps, buckles and velcro to equalize tension

**B) BACKREST COVER:**

1. Remove headrests (see NOTE 2)
2. Slip cover over backrest. Ensure cover is installed under seat belt
3. Pass top straps behind the seat so they go to floor (see NOTE 3)
4. Tuck in bottom of seat cover between seat backrest and metal bar (see NOTE 4)
5. With seat cushion in up position locate the straps (from step 3.) and secure to velcro tabs on seat cover (see NOTE 5)

- 6) Tuck in the 3 velcro straps through crevice and loop around the metal bar and secure (see NOTE 6)
- 7) Secure side velcro to the carpet side of seat backrest
- 8) Adjust all velcro for a uniform fit
- 9) Reinstall headrests (see NOTE 7)

**NOTES:**

<p>1) <b>SELF-LOCKING SUPER-GRIP® BUCKLE:</b></p> 	<p>5)</p> 
<p>2) <b>HEAD REST REMOVAL:</b>        A) - Insert paper clip into holes at base to release        - Lift off  <b>OR</b>        B) - Push in side release buttons        - Lift off        (If unable to remove consult dealership)</p> 	<p>6)</p> <p>Diagram F</p> 
<p>3) <b>Due to restricted space, a 4" x 30" piece of cardboard with 2 slits at one end will simplify the placing of the straps. If desired, the strip can be cut from the seat cover box.</b></p> 	<p>7) <b>RE-INSTALLATION OF HEADRESTS</b>        A) Ensure pre-cut holes in seat cover align with holes in base.        B) Replace headrests</p>
<p>4)</p> 	

**WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG.. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.**



Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438  
 Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com