If you have any comments or concerns, please feel free to contact our customer service department at:

Toll-free: 1-800-835-0438

OR

Email: info@gofia.com

SEAT COVERS BY

The Leader in Custom Fit FEATURING SUPER-GRIP®





## INSTALLATION INSTRUCTIONS FOR NP92-34/ Oe32-34/ SL62-34/ SP82-34/ TR42-34/ TRS42-34

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

## A) CUSHION COVERS:

- 1. Center cover on seat
- 2. Lift cushion halfway to up position
- 3. Insert strap through crevice and buckle

- 4. Attach velcro to carpet on underside of cushion
- 5. Adjust all straps, buckles and velcro to equalize tension

## B) BACKREST COVER:

- Slip cover over backrest. Ensure cover is installed under seat belt strap.
- 2. Starting with one side, tuck stretch fabric behind seat.
- 3. Repeat on other side
- 4. Tuck stretch fabric between headrest post and backrest Behind seat.
- 5. Pass strap with velcro behind the seat and down to the floor. (see notes below)
- 6. Secure to velcro on the bottom of seat cover
- 7. Adjust all velcro for a uniform fit

## **NOTES:**

1) SELF-LOCKING SUPER-GRIP® BUCKLE:



3) Due to restricted space, a 2" x 30" piece of cardboard with 2 slits at one end will simplify the placing of the straps. If desired, the strip can be cut from the seat cover box.







1) Seats with integrated seat airbags must be covered only with seat covers designed with openings.

WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG.. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.

fia

Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438 Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com