

SEAT COVERS
BY




FEATURING

SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS
FOR

NP92-90/ OE32-90/ SL62-90/ SP82-90/ TR42-90/ TRS42-90



Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

A) BACKREST COVER 40 side:

- 1) Unlatch backrest from back wall
- 2) Remove headrests (see note below)
- 3) Slip cover over backrest
- 4) Tuck flaps through crevice under backrest
- 5) Fold down backrest and attach flaps on velcro at back of cover
- 6) Re-latch backrest to back wall
- 7) Replace headrests (see notes)

B) BACKREST COVER 60 side:

- 1) Unlatch backrest from back wall
- 2) Remove headrests (see note below)
- 3) Slip cover over backrest under center seat belt positioning armrest through opening
- 4) Tuck flaps through crevice under backrest
- 5) Fold down backrest and attach flaps on velcro at back of cover
- 6) Re-latch backrest to back wall
- 7) Replace headrests (see notes)

C) ARMREST COVER

- 1) Fold armrest down
- 2) Slip cover over armrest and attach velcro

D) CUSHION COVERS X 2:

- 1) Center cover on seat
- 2) Tuck back of seat cover into crevice
- 3) Lift seat in up position and buckle straps
- 4) Apply side Velcro on cover to carpet under cushion
- 5) Adjust Velcro, straps and buckle to equalize tension


NOTES:

1) SELF-LOCKING SUPER-GRIP® BUCKLE:



2) HEAD REST REMOVAL:

- Push in side release buttons
- Lift off
- (If unable to remove consult dealership)



3) RE-INSTALLATION OF HEADRESTS

- A) Ensure pre-cut holes in seat cover align with holes in headrest base.
- B) Replace headrests

WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.



Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com

LIMITED 2 YEAR WARRANTY

Fia Inc. guarantees the original purchaser a limited 2 year warranty against manufacturer's defects in materials, workmanship and finish under normal use. The warranty is void if the product has been damaged resulting from product misuse, improper installation, product modifications or product neglect. The warranty applies to all Fia products and is limited to repair or replacement of the product. Warranty does not include cost of removal, installation, labor, freight and incidental or consequential damages.

Original purchaser must return defective merchandise along with the original purchase receipt to the original place of purchase for repair or replacement. Shipping charges will apply for any repair or replacement.

Buyer assumes all risk and liability whatsoever from the installation of Fia products. Vehicles equipped with supplemental restraint systems (air bags) deployed by impact should not be modified or covered by any aftermarket seat cover without consulting the vehicle manufacturer and Fia Inc. Fia Inc. assumes no liability for injury, loss, incidental or consequential damages in the event of an accident.

Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com