If you have any comments or concerns, please feel free to contact our customer service department at: Toll-free: 1-800-835-0438

OR

1) Move seat to most forward position

1) Center cover on the seat

2) Slip cover over backrest - pull down firmly

2) Pass the front strap under seat and buckle

Email: info@gofia.com

SEAT COVERS

FEATURING



THE SLIP RESISTANT FASTENING SYSTEM **INSTALLATION INSTRUCTIONS FOR**

OE37-31/ SL67-31/ SP87-31/ TR47-31



Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit. The Super Grip Buckles are self-locking. For proper usage, see diagram.

BACKREST COVERS:

- 3) Tuck flap through crevice and attach to velcro at back
- 4) Adjust velcro to equalize tension

CUSHION COVER - "40" PORTION:

- 3) Pass side straps around back of seat and buckle
- 4) Adjust straps and buckles to equalize tension

- **CUSHION COVER "60" PORTION:** 1) Align cover on seat and position seat belt through opening provided
- 2) Pass the strap that is attached to the flap by the seat belt cut-out through the seat belt opening under the seat and secure with side strap buckle or flap buckle (see note)
- 3) a) Seat with built-in cup holder. Pull down cup holder and position adhesive back velcro to align with velcro attached to back flap under top frame of cup holder
- b) Seat without cup holder. The back flap will adhere to back of seat without the use of adhesive back velcro
- 4) Pass front strap under seat and buckle
- 5) Pass side strap around the back of the seat and buckle
- 6) Adjust straps and buckles to equalize tension

ARMREST / STORAGE COMPARTMENT COVER

- 1) Open armrest / storage compartment
- 2) Center cover under armrest
- 3) Position adhesive backed velcro (supplied) to align with the velcro on cover. NOTE: BEFORE POSITIONING VELCRO, **CLEAN AREA WITH ALCOHOL SWAB PROVIDED**
- 4) Snug cover at back of console so the velcro on the cover is positioned through the crevice where lid and armrest / console are hinged
- 5) Secure the adhesive velcro on the inside back of console

ARMREST / STORAGE COMPARTMENT LID COVER

- 1) Open armrest / storage compartment
- 2) Slip Cover over lid
- 3) Snug cover at back corners of the lid

NOTES:

1) SELF-LOCKING SUPER-GRIP® BUCKLE:

2) HEAD REST REMOVAL:

OR B) - Push in side release buttons

(If unable to remove consult dealership)

A) - Insert paper clip into holes at base to release



A) For ease in installation, the zipper is longer than the cover. Tuck excess zipper under cover.

4) Position adhesive backed velcro (supplied) on underside of lid to align

4) RE-INSTALLATION OF HEADRESTS


with the velcro tabs on cover and attach

- Locate headrest base and put a small slit in the stretch fabric to accommodate each of the posts
- Replace headrests

5)



- Stretch fabric will not run



WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG.. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.

- Lift off

Lift off

Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438 Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com 6-21-13