

If you have any comments or concerns,
please feel free to contact our
customer service department at:
Toll-free: 1-800-835-0438
OR
Email: info@gofia.com

SEAT COVERS
BY

fia
The Leader in Custom Fit

FEATURING

SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM

INSTALLATION INSTRUCTIONS
FOR

NP98-16/ Oe38-16/ SL68-16/ SP88-16/ TR48-16/ TRS48-16



Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit.

- A) BACKREST COVER – “40” PORTION X 2:**
- 1) Remove head rest (see note)
 - 2) Open zipper
 - 3) Slip cover over backrest under seat belt
 - 4) Close zipper (see note)
 - 5) Tuck flaps under backrest and attach to Velcro at back
 - 6) Adjust Velcro to equalize tension
 - 7) Replace headrests (see note)


- B) CUSHION COVER - “40” PORTION X 2:**
- 1) Center cover on the seat
 - 2) Pass the front strap under seat and buckle to back flap
 - 3) Pass side straps around back of seat and buckle
 - 4) Adjust straps and buckles to equalize tension

- C) CUSHION COVER –“20” PORTION X 1:**
- 1) Repeat “B)”

- D) BACKREST COVER – “20” PORTION X 1**
- 1) Open console
 - 2) Center cover under armrest
 - 3) Position adhesive back Velcro (supplied) to align with the Velcro on side of cover. **NOTE: BEFORE POSITIONING VELCRO, CLEAN AREA WITH ALCOHOL SWAB PROVIDED.**
 - 4) Snug cover at back of console so the Velcro on the cover meets the hinge
 - 5) Secure the adhesive back Velcro inside the console

NOTES:

- 1) SELF-LOCKING SUPER-GRIP® BUCKLE:**



- 3) SEATS WITH SIDE ARMRESTS:**

- Locate opening in stretch fabric
- Slip armrest through opening

- 4) ZIPPERS:**

- For ease in installation the zipper is longer than the cover.
- Tuck excess zipper under cover


- 2) HEAD REST REMOVAL:**

- A) - Insert paper clip into holes at base to release
- Lift off

OR

- B) - Push in side release buttons
- Lift off

(If unable to remove consult dealership)



- 5) RE-INSTALLATION OF HEADRESTS**

- A) Ensure pre-cut holes in seat cover align with holes in base.
B) Replace headrests

WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG.. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.

fia

Fia Inc. Winnipeg, Canada R3L 0N3 Telephone (204) 475-0515 Toll-Free: 1-800-835-0438
Fax: (204) 284-8246 E-Mail: info@gofia.com Website: www.gofia.com

4-22-14