

CUSTOM SEAT COVERS
BY


If you have any comments or concerns,
please feel free to contact our
customer service department at:
Toll-free: 1-800-835-0438
OR
Email: info@gofia.com



FEATURING

SUPER-GRIP®

THE SLIP RESISTANT FASTENING SYSTEM



INSTALLATION INSTRUCTIONS
FOR
OE39-5/ SL69-5/ SP89-5/ TR49-5

Thank you for purchasing one of our fine quality products. Your seat cover is engineered from high quality materials and designed with precision to give you a long-lasting, well-adjusted fit. The **Super Grip Buckles** are self-locking. For proper usage, see diagram.

INSTRUCTIONS:

A) BACKREST COVERS – “40” PORTIONS:

- 1) Open zipper closure in seat cover
- 2) Install cover under seat belt
- 3) Close zipper (see note)
- 4) Tuck flap through crevice and attach to velcro at back
- 5) Adjust velcro to equalize tension

B) CUSHION COVER - “40” PORTIONS:

- 1) Center cover on the seat
- 2) Pass the front strap under seat and buckle
- 3) Pass side straps around back of seat and buckle
- 4) Adjust straps and buckles to equalize tension

C) CUSHION COVER – “20” PORTION:


- 1) Center cover on the seat
- 2) Tuck the back part of cushion cover through seat crevice
- 3) Pass the front straps under the seat and secure to center buckle
- 4) Pass the side straps under back corners of center seat and secure to end buckles
- 5) Adjust straps and buckles to equalize tension

D) BACKREST COVER – “20” PORTION:

- 1) Open armrest / business console
- 2) Center cover under armrest
- 3) Position adhesive backed velcro (supplied) to align with the velcro on cover. **NOTE: BEFORE PLACING VELCRO, CLEAN AREA WITH ALCOHOL SWAB PROVIDED.**
- 4) Snug cover at back of armrest so that the velcro attached to cover meets the metal hinge
- 5) Secure the adhesive velcro to the hinge to align with velcro on cover

NOTES:

1) SELF-LOCKING SUPER-GRIP® BUCKLE:



3) SEATS WITH RELEASE LEVERS AND POWER CONTROLS:

- A) Locate levers or controls once seat cover is installed
- B) Slit hole(s) into the stretch fabric. **THE STRETCH FABRIC WILL NOT RUN**

2) ZIPPER:

- A) For ease in installation, the zipper is longer than the cover. Tuck excess zipper under cover.

WARNING: SEATS WITH INTEGRATED SEAT AIRBAGS MUST BE COVERED ONLY WITH SEATCOVERS DESIGNED WITH OPENINGS THAT WILL NOT INTERFERE WITH THE DEPLOYMENT OF THE AIRBAG. NEVER INSTALL SEAT COVERS WITHOUT THESE OPENINGS AS THIS MAY INTERFERE WITH THE PROPER DEPLOYMENT OF THE AIR BAGS AND COULD RESULT IN SERIOUS INJURY.

