

Tach/Fuel Injection Adapter PN 8910-EIS

ONLINE PRODUCT REGISTRATION: Register your MSD product online. Registering your product will help if there is ever a warranty issue with your product and helps the MSD R&D team create new products that you ask for! Go to www.msdperformance.com/registration.

The PN 8910-EIS (Electronic Ignition System) will interpret the trigger signal into a signal the factory fuel injection and tachometer will recognize when an MSD Ignition is installed. This Adapter is designed for current limiting ignition systems (no ballast resistor).

INSTALLATION

- 1. Mount the Tach Adapter in a location away from direct engine heat making sure the wires reach the MSD unit and the coil. The PN 8860 Magnectic Pickup extension harness may be used.
- 2. Locate the White wire coming from the MSD and disconnect it from the factory wire that it was connected to (this should be the points or ignition amplifier wire). Seal the White wire as it will not be used anymore. Leave the other MSD wires connected.
- 3. Connect the Black wire of the PN 8910-EIS to the wire coming from the points or ignition amplifier (This is the same wire that the White wire of the MSD was connected to).
- 4. Splice the Red wire of the PN 8910-EIS to the small Red wire of MSD Ignition.
- 5. Connect the 2-pin magnetic pickup connector to the corresponding connector of the MSD.




Figure 1 Wiring the Tach Adapter.



TECH NOTES

Service

In case of malfunction, this MSD component will be repaired free of charge according to the terms of the warranty. When returning MSD components for warranty service, **Proof of Purchase** must be supplied for verification. After the warranty period has expired, repair service is based on a minimum and maximum fee.

All returns must have a Return Material Authorization (RMA) number issued to them before being returned. To obtain an RMA number please contact MSD Customer Service at 1 (888) MSD-7859 or visit our website at www.msdperformance.com/rma to automatically obtain a number and shipping information. When returning the unit for repair, leave all wires at the length in which you have them installed. Be sure to include a detailed account of any problems experienced, and what components and accessories are installed on the vehicle. The repaired unit will be returned as soon as possible using Ground shipping methods (ground shipping is covered by warranty). For more information, call MSD at (915) 855-7123. MSD technicians are available from 7:00 a.m. to 5:00 p.m. Monday - Friday (mountain time).

Limited Warranty

MSD warrants this product to be free from defects in material and workmanship under its intended normal use*, when properly installed and purchased from an authorized MSD dealer, for a period of one year from the date of the original purchase. This warranty is void for any products purchased through auction websites. If found to be defective as mentioned above, it will be repaired or replaced at the option of MSD. Any item that is covered under this warranty will be returned free of charge using Ground shipping methods.

This shall constitute the sole remedy of the purchaser and the sole liability of MSD. To the extent permitted by law, the foregoing is exclusive and in lieu of all other warranties or representation whether expressed or implied, including any implied warranty of merchantability or fitness. In no event shall MSD or its suppliers be liable for special or consequential damages.

*Intended normal use means that this item is being used as was originally intended and for the original application as sold by MSD. Any modifications to this item or if it is used on an application other than what MSD markets the product, the warranty will be void. It is the sole responsibility of the customer to determine that this item will work for the application they are intending. MSD will accept no liability for custom applications.

MSD • WWW.MSDPERFORMANCE.COM • (915) 857-5200 • FAX (915) 857-3344 © 2013 MSD LLC FRM29726 Revised 01/14 Printed in U.S.A.